

Platform Guide: 10000 Series

MAN-0408-07



Table of Contents

Legal Notices.....	7
Legal Notices.....	7
The 10000 Series Platform.....	9
About 10000 Series models.....	9
About the platform.....	9
Hardware included with the platform.....	10
Peripheral hardware requirements.....	11
LCD panel.....	11
About the LCD menus.....	11
Using the LCD panel.....	13
Indicator LEDs.....	14
Status LED.....	14
Alarm LED.....	15
Power supply LEDs.....	15
Indicator LED behavior.....	15
Defining custom alerts.....	15
Platform interfaces.....	16
About managing interfaces.....	16
About 40GbE QSFP+ interfaces.....	19
Network interface LED behavior.....	21
Transceiver module specifications.....	22
Cable pinout specifications.....	22
Always-On Management.....	22
AOM Command Menu options.....	22
Accessing the AOM Command Menu from the serial console.....	23
Configuring the management network.....	24
Accessing the AOM Command Menu using SSH.....	24
About the host console capture buffer.....	25
Platform Installation.....	27
About installing the platform.....	27
Determining which rack mounting kit to use.....	27
About the front-mounting kit.....	27
Front-mounting kit hardware.....	27
Installing using a front-mounting kit.....	27
About the quick-install rail kit.....	28
Installing the rail lock brackets.....	29
About grounding the platform.....	29

Connecting the ground lug to the ground terminal.....	30
About powering the platform.....	30
Connecting the cables and other hardware.....	30
Configuring a management IP address using the LCD panel.....	31
Licensing the platform.....	32
Platform Maintenance.....	33
About maintaining the platform.....	33
About AC power supplies.....	33
Installing an AC power supply.....	34
About DC power supplies.....	34
Wiring the DC power supply terminal block.....	36
Installing a DC power supply.....	37
About the fan tray.....	38
Replacing the fan tray.....	39
About the hard disk drives.....	40
Identifying a faulty hard disk drive.....	41
Replacing a hard disk drive tray.....	42
Environmental Guidelines.....	45
General environmental and installation guidelines.....	45
Guidelines for AC-powered equipment.....	46
Guidelines for DC-powered equipment.....	47
NEBS platform guidelines.....	47
Platform airflow diagram.....	47
Platform Specifications.....	49
General specifications for system features.....	49
Platform hardware specifications - 10000 Series.....	49
Platform hardware specifications - 10150 Series.....	50
Platform environmental operating specifications.....	51
Platform power specifications - 10000s/10200v.....	51
Platform power specifications - 10050 Series.....	52
Platform power specifications - 10200v-SSL.....	53
Platform power specifications - 10150 Series.....	53
Safety requirements.....	54
EMC requirements.....	54
Acoustic, airflow, and altitude specifications.....	55
China RoHS Requirements.....	57
Hazardous substance levels for China.....	57
Repackaging Guidelines.....	59

About repackaging the platform.....59

Repackaging the platform.....59

Returned Material Data Security Statement.....61

 About returned material data security.....61

 About memory technologies used in F5 equipment.....61

 Volatile memory.....61

 Battery-backed volatile memory.....61

 Non-volatile memory.....61

 About removing data from F5 components.....62

 Removing sensitive data from storage drives.....62

 Removing IP address data from Always-On Management.....63

 Removing sensitive data from an internal hardware security module (HSM).....63

Legal Notices

Legal Notices

Publication Date

This document was published on April 5, 2016.

Publication Number

MAN-0408-07

Copyright

Copyright © 2016, F5 Networks, Inc. All rights reserved.

F5 Networks, Inc. (F5) believes the information it furnishes to be accurate and reliable. However, F5 assumes no responsibility for the use of this information, nor any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright, or other intellectual property right of F5 except as specifically described by applicable user licenses. F5 reserves the right to change specifications at any time without notice.

Trademarks

AAM, Access Policy Manager, Advanced Client Authentication, Advanced Firewall Manager, Advanced Routing, AFM, APM, Application Acceleration Manager, Application Security Manager, AskF5, ASM, BIG-IP, BIG-IP EDGE GATEWAY, iWorkflow, Cloud Extender, Cloud Manager, CloudFucious, Clustered Multiprocessing, CMP, COHESION, Data Manager, DDoS Frontline, DDoS SWAT, Defense.Net, defense.net [DESIGN], DevCentral, DevCentral [DESIGN], DNS Express, DSC, DSI, Edge Client, Edge Gateway, Edge Mobile, Edge Mobility, Edge Portal, ELEVATE, EM, ENGAGE, Enterprise Manager, F5, F5 [DESIGN], F5 Agility, F5 Certified [DESIGN], F5 Networks, F5 SalesXchange [DESIGN], F5 Synthesis, f5 Synthesis, F5 Synthesis [DESIGN], F5 TechXchange [DESIGN], Fast Application Proxy, Fast Cache, FCINCO, Global Traffic Manager, GTM, GUARDIAN, iApps, IBR, iCall, iControl, iHealth, Intelligent Browser Referencing, Intelligent Compression, IPv6 Gateway, iQuery, iRules, iRules OnDemand, iSession, L7 Rate Shaping, LC, Link Controller, LineRate, LineRate Point, LineRate Precision, LineRate Systems [DESIGN], Local Traffic Manager, LROS, LTM, Message Security Manager, MobileSafe, MSM, OneConnect, Packet Velocity, PEM, Policy Enforcement Manager, Protocol Security Manager, PSM, Ready Defense, Real Traffic Policy Builder, SalesXchange, ScaleN, SDAS (except in Japan), SDC, Signalling Delivery Controller, Solutions for an application world, Software Designed Application Services, Silverline, SSL Acceleration, SSL Everywhere, StrongBox, SuperVIP, SYN Check, SYNTHESIS, TCP Express, TDR, TechXchange, TMOS, TotALL, TDR, TMOS, Traffic Management Operating System, Traffix, Traffix [DESIGN], Transparent Data Reduction, UNITY, VAULT, vCMP, VE F5 [DESIGN], Versafe, Versafe [DESIGN], VIPRION, Virtual Clustered Multiprocessing, WebSafe, and ZoneRunner, are trademarks or service marks of F5 Networks, Inc., in the U.S. and other countries, and may not be used without F5's express written consent.

All other product and company names herein may be trademarks of their respective owners.

Export Regulation Notice

This product may include cryptographic software. Under the Export Administration Act, the United States government may consider it a criminal offense to export this product from the United States.

RF Interference Warning

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

Any modifications to this device, unless expressly approved by the manufacturer, can void the user's authority to operate this equipment under part 15 of the FCC rules.

Canadian Regulatory Compliance

This Class A digital apparatus complies with Canadian ICES-003.

Standards Compliance

This product conforms to the IEC, European Union, ANSI/UL and Canadian CSA standards applicable to Information Technology products at the time of manufacture.

VCCI Class A Compliance

This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take corrective actions. VCCI-A

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

The 10000 Series Platform

About 10000 Series models

The BIG-IP® 10000 Series platform is a powerful system that is capable of managing traffic for any size of enterprise. This platform series includes models that support either hard disk drives (HDDs) or solid-state drives (SSDs).

F5 offers three performance levels of SSL offload in the 10000 Series: the 10000s, 10200v, and 10200v-SSL. The 10200v-SSL platform features high-performance SSL hardware that frees servers from the task of encrypting and decrypting data.

The 10000 Series platform is available with a FIPS-certified hardware security module (HSM) as a factory-installed option (10200v-FIPS and 10350v-FIPS). The 10150 Series platform is available in Network Equipment-Building System (NEBS) compliant versions (10150s-NEBS and 10350v-NEBS).

Note: FIPS is not supported in vCMP guests.

Please see the data sheet at <https://f5.com/products/platforms> for more information.

About the platform

Before you install this platform, review information about the controls and ports located on both the front and back of the platform.

On the front of the platform, you can reset the unit using the LCD control buttons and view the indicator LEDs for disk drive access. You can also use the front-panel LEDs to assess the condition of the platform. On the back, you can power off the unit.



Figure 1: Front view of the 10000 platform

1. Management 10/100/1000 port
2. USB ports
3. Console serial port
4. Serial (hard-wired) failover port
5. 1/10G SFP+ ports
6. 40GbE QSFP+ fiber ports
7. Indicator LEDs

- 8. LCD display
- 9. LCD control buttons
- 10. Disk drive bay 1
- 11. Disk drive bay 2

The back of the platform includes two AC power supplies and the fan tray.



Figure 2: Back view of the platform

- 1. Power input panel 1
- 2. Power input panel 2
- 3. Fan tray
- 4. Chassis ground lugs

Hardware included with the platform

This platform should include all of the hardware components listed here.

Quantity	Hardware
2	Power cables (black), AC power only
	<i>Note: The power cables included with this unit are for exclusive use with this unit and should not be used with other electrical appliances.</i>
2	DC terminal block plug, DC power option only
1	RJ45 to RJ45 failover cable, CAT 5 crossover (blue)
1	RJ45 to DB9 console port cable (beige)
1	RJ45F to RJ45M rolled adapter (beige)
1	Quick-install rail kit (left and right rails)
2	Rail lock brackets with captive screw (left and right)
1	Front-mounting kit (left and right brackets)
1	Front bezel
2	SFP+ transceiver modules

Peripheral hardware requirements

For each platform, you might need to provide additional peripheral hardware. If you plan to remotely administer the system, it would be helpful to have a workstation already connected to the same subnet as the management interface.

Type of hardware	Description
Network hubs, switches, or connectors to connect to the platform network interfaces	You must provide networking devices that are compatible with the network interface cards that are installed in the platform. You can use either 10/100/1000/10000-Gigabit or 40-Gigabit Ethernet switches.
External USB CD/DVD drive or USB flash drive	You can use any USB-certified CD/DVD mass storage device or a USB flash drive for installing upgrades and for system recovery. <i>Note: External CD/DVD drives must be externally powered.</i>
Serial console	You can remotely manage the platform by connecting to a serial console terminal server through the console port. <i>Important: In the event that network access is impaired or not yet configured, the serial console might be the only way to access the unit. You should perform all installations and upgrades using the serial console, as these procedures require reboots, in which network connectivity is lost temporarily.</i>
Management workstation on the same IP network as the platform	You can use the default platform configuration if you have a management workstation set up.

LCD panel

The LCD panel provides the ability to manage the unit without attaching a console or network cable.




Figure 3: The LCD panel and control buttons

About the LCD menus

There are three menus on the LCD panel. You can configure the display options to meet your needs.

LCD config menu

You can use the LCD config menu to adjust the display properties of the LCD panel.

Option	Description
Heartbeat	Enables (checked) or disables (unchecked) the heartbeat panel on the LCD. This heartbeat does not affect the failover mechanism of the system.
Backlight	Specifies an LCD screen backlighting option. Select from these options: <ul style="list-style-type: none"> • ON enables the backlight. • GRAY enables the software to specify when the backlight is illuminated. • OFF disables the backlight.
Contrast	Sets the contrast of the LCD.
On Brightness	Adjusts LCD backlight brightness.
Off Brightness	Controls the brightness of the LCD when the backlight is off.

System menu

You can use the System menu to view options for rebooting, halting, and netbooting the hardware. This menu also provides options for configuring the management interface.

Option	Description
DHCP	Controls the use of DHCP. Select from these options: <ul style="list-style-type: none"> • disabled (default) • enabled
Management	Changes the management interface information. Select from these options: <ul style="list-style-type: none"> • Address Type indicates whether to use an IPv4 or IPv6 address. • Mgmt IP sets the management interface IP address. You can use an IPv4 or IPv6 address. • Prefix Length sets the length of the routing prefix for the IPv4 or IPv6 management IP address. • Mgmt Gateway sets the default route for the management interface. This route is necessary if you plan to manage the unit from a different subnetwork. • Commit saves your changes.
Serial Speed	Changes the baud rate of the management serial port. Select from these options: <ul style="list-style-type: none"> • 9600 • 19200 (default) • 57600 • 115200
Reboot	Reboots the unit.
Halt	Halts the unit.
Netboot	Boots the unit over an IP network. Select this option if you are installing software from a PXE server.

Screens menu

You can use the Screens menu to specify the information that is displayed on the default screens.

Option	Description
DateScreen	Displays the date and time.
InfoScreen	Displays the information screen.
RaidScreen	Displays the RAID status screen.
<i>Note: Not available on solid-state drive (SSD) platforms.</i>	
VersionScreen	Displays product version information.

Using the LCD panel

Put the LCD panel into Menu mode to manage the platform using the LCD menus and control buttons.

Press the X button to activate Menu mode for the LCD.

The Left Arrow, Right Arrow, Up Arrow, and Down Arrow buttons are functional only when the LCD is in Menu mode.

Pausing on a screen

Normally, the screens cycle on the LCD panel at a constant rate, but you can pause on a specific screen.

Push the Check button to toggle the LCD screen between Hold and Rotate modes.

In Hold mode, a single screen is displayed. The Rotate mode changes the screen displayed on the LCD every four seconds.

Powering on the unit

Use the LCD control buttons to power on the unit.

Press the Check button to power on a unit that is shut down.

Halting the unit

Use the LCD control buttons to halt the unit. You should halt the unit before you power it down or reboot it using the LCD menu options.

1. Press the X button, then use the arrow keys to navigate to the System menu.
2. Press the Check button.
3. Navigate to the Halt menu.
4. Press the Check button.
5. Press the Check button again at the confirmation screen.

Wait 60 seconds before powering the machine off or rebooting it.

Putting the unit in standby mode

Use the LCD control buttons to put the unit into standby mode.

Hold the X button for four seconds to put the unit in standby mode and power off the host subsystem.
F5[®] recommends that you halt the system before you power off the system in this manner.

Resetting the unit

Use the LCD control buttons to reset the unit.

Hold the Check button for four seconds to reset the unit.
You should only use this option after you halt the unit.

Clearing alerts

Use the LCD control buttons to clear alerts from the LCD screen.

Press the Check button to clear any alerts on the LCD screen.
You must clear any alerts on the screen before you can use the LCD panel.

Indicator LEDs

The behavior of each LED indicates the status of the system.

Status LED

The status LED indicate the operating state of the system.

State	Description
off/none	System is halted and powered down.
green solid	System is running in normal mode. Also indicates that the system is in an Active state of a device group.
yellow solid	System is running in an impaired mode. The condition is not considered to be significant enough to be considered an alarm condition. Also indicates that the system is the Standby member of a device group.
yellow blinking (with traffic)	The system is not under host computer control. This might be due to the host being halted or in EUD mode, or due to a software or hardware problem that interferes with the host's control of the LED.

Alarm LED

The alarm LED indicate system alarm conditions and the severity of the alarm condition.

There are five levels of messages.

Note: The alarm LED might continue to display until alerts are cleared using the LCD panel.

State	Description
off/none	Informational or no alarm conditions present. System is operating properly.
yellow solid	Warning (0). System may not be operating properly, but the condition is not severe or potentially damaging.
yellow blinking	Error (1). System is not operating properly, but the condition is not severe or potentially damaging.
red solid	Alert (2) or Critical (3). System is not operating properly, and the condition is potentially damaging.
red blinking	Emergency (4). System is not operating, and the condition is potentially damaging.

Power supply LEDs

The power supply LEDs indicate the operating state of the power supplies.

Power 1 state	Power 2 state	Description
green solid	green solid	Power supply is present and operating properly. Also indicates when the system is in power standby mode.
yellow solid	yellow solid	Power supply is present, but not operating properly.
off/none	off/none	No power supply present.

Indicator LED behavior

The indicator LEDs behave in a specific manner to indicate system or component status.

Behavior	Description
off (none)	LED is not lit and does not display any color.
solid	LED is lit and does not blink.
blinking	LED turns on and off at a regular frequency.
intermittent	LED turns on and off with an irregular frequency and might sometimes appear solid.

Defining custom alerts

The `/etc/alertd/alert.conf` and the `/config/user_alert.conf` files on the BIG-IP® system define alerts that cause the indicators to change. The `/etc/alertd/alert.conf` file defines standard system alerts, and the `/config/user_alert.conf` file defines custom settings. You should edit only the `/config/user_alert.conf` file.

1. Open a command prompt on the system.
2. Change to the `/config` directory.

```
cd /config
```
3. Using a text editor, such as `vi` or `Pico`, open the `/config/user_alert.conf` file.
4. Edit the file, as needed.
For example, add these lines to the end of the file to create a custom alert in which the front panel LEDs indicate when a node is down:

```
alert BIGIP_MCPD_MCPDERR_POOL_MEMBER_MON_DOWN "Pool member (.?):(.?) monitor
status down."
{
  snmptrap OID=".1.3.6.1.4.1.3375.2.4.0.10";
  lcdwarn description="Node down" priority="1"
}
alert BIGIP_MCPD_MCPDERR_NODE_ADDRESS_MON_DOWN "Node (.?) monitor status
down." {
  snmptrap OID=".1.3.6.1.4.1.3375.2.4.0.12";
  lcdwarn description="Node address down" priority="1"
}
alert BIGIP_MCPD_MCPDERR_POOL_MEMBER_MON_UP "Pool member (.?):(.?) monitor
status up."
{
  snmptrap OID=".1.3.6.1.4.1.3375.2.4.0.11"
}
alert BIGIP_MCPD_MCPDERR_NODE_ADDRESS_MON_UP "Node (.?) monitor status up."
{
  snmptrap OID=".1.3.6.1.4.1.3375.2.4.0.13"
}
```

5. Save the file and exit the text editor.

Platform interfaces

Every platform includes multiple interfaces. The exact number of interfaces that are on the system depends on the platform type.

Each interface on the platform has a set of properties that you can configure, such as enabling or disabling the interface, setting the requested media type and duplex mode, and configuring flow control.

About managing interfaces

You can use the Traffic Management Shell (`tmsh`) or the BIG-IP® Configuration utility to manage platform interfaces.

Viewing the status of a specific interface using `tmsh`

You can use `tmsh` to view the status of a specific interface on a platform.

1. Open the Traffic Management Shell (`tmsh`).

```
tmsh
```


2. Change to the network module.

```
net
```

The system prompt updates with the module name: user@bigip01 (Active) (/Common) (tmsh.net) #

3. Display the current status of a specific interface.

```
show interface <interface_key>
```

This is an example of the output that you might see when you run this command on interface 1.1:

```
-----
Net::Interface
Name  Status  Bits  Bits  Pkts  Pkts  Drops  Errs      Media
      In    Out   In    Out
-----
1.1   up      5.9T   0    7.3G   0    7.3G   0    10000SR-FD
```

Viewing the status of all interfaces using tmsh

You can use tmsh to view the status of all interfaces on the platform.

1. Open the Traffic Management Shell (tmsh).

```
tmsh
```

2. Change to the network module.

```
net
```

The system prompt updates with the module name: user@bigip01 (Active) (/Common) (tmsh.net) #

3. Display the current status of all interfaces.

```
show interface
```

This is an example of the output that you might see when you run this command:

```
-----
Net::Interface
Name  Status  Bits  Bits  Pkts  Pkts  Drops  Errs      Media
      In    Out   In    Out
-----
1.1   up      5.9T   0    7.3G   0    7.3G   0    10000SR-FD
1.2   miss    0      0     0     0     0     0     none
1.3   miss    0      0     0     0     0     0     none
1.4   miss    0      0     0     0     0     0     none
1.5   miss    0      0     0     0     0     0     none
1.6   miss    0      0     0     0     0     0     none
1.7   miss    0      0     0     0     0     0     none
1.8   miss    0      0     0     0     0     0     none
1.9   miss    0      0     0     0     0     0     none
1.10  miss    0      0     0     0     0     0     none
1.11  miss    0      0     0     0     0     0     none
1.12  miss    0      0     0     0     0     0     none
1.13  miss    0      0     0     0     0     0     none
1.14  miss    0      0     0     0     0     0     none
1.15  miss    0      0     0     0     0     0     none
1.16  miss    0      0     0     0     0     0     none
1.17  uninit   0      0     0     0     0     0     none
1.18  uninit   0      0     0     0     0     0     none
1.19  uninit   0      0     0     0     0     0     none
1.20  uninit   0      0     0     0     0     0     none
1.21  uninit   0      0     0     0     0     0     none
1.22  uninit   0      0     0     0     0     0     none
1.23  uninit   0      0     0     0     0     0     none
1.24  uninit   0      0     0     0     0     0     none
```

2.1	uninit	0	0	0	0	0	0	0	none
2.2	uninit	0	0	0	0	0	0	0	none
2.3	uninit	0	0	0	0	0	0	0	none
2.4	uninit	0	0	0	0	0	0	0	none
2.5	miss	0	0	0	0	0	0	0	none
2.6	miss	0	0	0	0	0	0	0	none
mgmt	up	182.1G	6.8G	41.2M	6.0M	0	0	0	1000T-FD

Viewing the status of all interfaces using the Configuration utility

You can use the BIG-IP® Configuration utility to view the status of all interfaces on the platform.

1. On the Main tab, click **Network > Interfaces > Interface List**.
This displays the list of available interfaces.
2. On the menu bar, click **Statistics**.
The Statistics screen for all interfaces opens.

About interface media type and duplex mode

All interfaces on the system default to auto-negotiate speed and full duplex settings. We recommend that you also configure any network equipment that you plan to use with the system to auto-negotiate speed and duplex settings. If you connect the system to network devices with forced speed and duplex settings, you must force the speed and duplex settings of the system to match the settings of the other network device.

Important: *If the system is attempting to auto-negotiate interface settings with an interface that has the speed and duplex settings forced (that is, auto-negotiation is disabled), you will experience severe performance degradation. This applies to 10GbE and 40GbE interfaces.*

By default, the media type on interfaces is set to automatically detect speed and duplex settings, but you can specify a media type as well. Use the following syntax to set the media type:

```
tmsh modify net interface <interface_key> media <media_type> | auto
```

If the media type does not accept the duplex mode setting, a message appears. If media type is set to `auto`, or if the interface does not accept the duplex mode setting, the duplex setting is not saved to the `/config/bigip_base.conf` file.

Important: *Auto-MDI/MDIX functionality is retained when you manually configure an interface to use specific speed and duplex settings. You can use either a straight-through cable or a crossover cable when media settings are forced, and you will be able to successfully link to either DTE or DCE devices.*

Valid media types

This table lists the valid media types for the `tmsh interface` command.

Note: *This platform might not support all of the media type options that are available in the Traffic Management Shell (tmsh).*

10BaseT half	100BaseTX full
10BaseT full	1000BaseLX full
10GBaseER full	1000BaseCX full

10GBaseLR full	1000BaseT half
10GBaseSR full	1000BaseT full
10GBaseT full	1000BaseSX full
10SFP+Cu full	auto
40GBaseSR4 full	none
40GBaseLR4 full	no-phy
100BaseTX half	

Viewing valid media types for an interface

You can use `tmsh` to view the valid media types for an interface.

Note: *This platform might not support all of the media type options that are available in `tmsh`.*

1. Open the Traffic Management Shell (`tmsh`).

```
tmsh
```

2. Change to the network module.

```
net
```

```
The system prompt updates with the module name: user@bigip01 (Active) (/Common) (tmsh.net) #
```

3. Display the valid media types for a specific interface.

```
list interface <interface_key> media-capabilities
```

Important: *In all Gigabit Ethernet modes, the only valid duplex mode is full duplex.*

This is an example of the output that you might see when you run this command on interface 1.3:

```
net interface 1.3 {
  media-capabilities {
    none
    auto
    10T-FD
    10T-HD
    100TX-FD
    100TX-HD
    1000T-FD
    1000T-HD
  }
}
```

About 40GbE QSFP+ interfaces

On platforms that include QSFP+ interface ports, you can use the ports as a single 40GbE port or as four 10GbE SFP+ ports.

The QSFP+ ports (2.5 and 2.6) default to 40GbE. The cable that you use when operating at 40GbE is an industry-standard OM3 qualified multi-mode fiber optic cable with female MPO/MTP connectors at both ends. You must provide your own cable for 40GbE operation.

You can also disable the 40GbE bundle and use them as individual 10GbE ports (1.1-1.4, 1.5-1.8, 1.9-1.12, and 1.13-1.16) using a QSFP+ breakout cable. This cable has a female MPO/MTP connector at one end,

which connects to the QSFP+ port, and four LC duplex connectors at the other end, which connect to SFP+ modules on an upstream switch.

Note: If you are using a breakout cable for 10GbE connectivity, you should use the supported distance as detailed in the Specifications for fiber QSFP+ modules section of this platform guide and not the Specifications for fiber SFP+ modules section.



Figure 4: An example of a QSFP+ breakout cable

You can order these QSFP+ components from F5[®] Networks:

- QSFP+ breakout cables (MTP to LC), provided as a pair, in these lengths:
 - 1 meter (F5-UPG-QSFP+-1M-2)
 - 3 meter (F5-UPG-QSFP+-3M-2+)
 - 10 meter (F5-UPG-QSFP+-10M-2)
- F5-branded 40GbE QSFP+ transceiver modules (F5-UPG-QSFP+)

Configuring bundling for 40GbE QSFP+ interfaces using tmsh

You can use `tmsh` to configure bundling for the 40GbE QSFP+ interfaces on a platform. When you disable bundling, you can use the 40GbE ports as individual 10GbE ports.

1. Open the Traffic Management Shell (`tmsh`).

```
tmsh
```

2. Change to the network module.

```
net
```

The system prompt updates with the module name: `user@bigip01 (Active) (/Common) (tmsh.net) #`

3. Configure bundling for a specific interface, where `<interface_key>` is 2.1, 2.2, 2.3, or 2.4.

```
modify interface <interface_key> bundle [enabled | disabled]
```

Note: When a 2.x port is bundled, the LEDs for the 10GbE ports remain OFF. When a 2.x port is unbundled, the 40GbE LEDs remain OFF.

Configuring bundling for 40GbE QSFP+ interfaces using the Configuration utility

You can use the BIG-IP[®] Configuration utility to configure bundling for the 40GbE QSFP+ interfaces on a platform. When you disable bundling, you can use the 40GbE ports as individual 10GbE ports.

1. On the Main tab, click **Network > Interfaces > Interface List**.
This displays the list of available interfaces.
2. Click an interface name.
The properties screen for that interface opens.
3. For the **Bundled** setting, select whether to enable or disable bundling.
4. Click **Update**.

Network interface LED behavior

The appearance and behavior of the network interface LEDs on the platform indicate network traffic activity, interface speed, and interface duplexity.

RJ45 Copper interface LED behavior

The appearance and behavior of the RJ45 network interface LEDs indicate network traffic activity, interface speed, and interface duplexity.

Link	Speed LED	Activity LED
No Link/Idle	Not lit	Not lit
10Mbit/s, half duplex	Yellow blinking (with traffic)	Yellow blinking (with traffic)
10Mbit/s, full duplex	Yellow blinking (with traffic)	Green blinking (with traffic)
100Mbit/s, half duplex	Yellow solid	Yellow blinking (with traffic)
100Mbit/s, full duplex	Yellow solid	Green blinking (with traffic)
1Gbit/s, half duplex	Green solid	Yellow blinking (with traffic)
1Gbit/s, full duplex	Green solid	Green blinking (with traffic)

SFP port LED behavior

The appearance and behavior of the SFP optical interface LEDs indicate network traffic activity, interface speed, and interface duplexity.

Link	Speed LED	Activity LED
No link/Idle	Not lit	Not lit
1 Gbit/s, half duplex	Green solid	Yellow blinking (with traffic)
1 Gbit/s, full duplex	Green solid	Yellow solid

SFP+ port LED behavior

The appearance and behavior of the SFP+ optical interface LEDs indicate network traffic activity, interface speed, and interface duplexity.

Link	Speed LED	Activity LED
No link/Idle	Not lit	Not lit
1 Gbit/s, full duplex	Yellow solid	Green blinking (with traffic)
10 Gbit/s, full duplex	Green solid	Green blinking (with traffic)

Link	Speed LED	Activity LED
40 Gbit/s, full duplex	Green solid	Green blinking (with traffic)
<i>Note: Applies only to bundled 10GbE interfaces.</i>		

QSFP+ port LED behavior

The appearance and behavior of the QSFP+ optical interface LEDs indicate network traffic activity, interface speed, and interface duplexity.

Link	Speed LED	Activity LED
No link/Idle	Not lit	Not lit
40 Gbit/s, full duplex	Green solid	Green blinking (with traffic)

Transceiver module specifications

For current specification information for optical transceivers that are supported by this platform, see *F5[®] Platforms: Accessories*.

Cable pinout specifications

For current pinout information for this platform, see *F5[®] Platforms: Accessories*.

Always-On Management

The Always-On Management (AOM) subsystem enables you to manage the system remotely using serial console or SSH, even if the host is powered down. The AOM Command Menu operates independently of the Traffic Management Operating System[®] (TMOS[®]).

You can use the command menu to reset the unit if TMOS has locked up, or get access to TMOS directly, so that you can configure it from the command-line interface.

Note: The available functionality and options in AOM vary depending on the platform type.

AOM Command Menu options

The AOM Command Menu provides the AOM options for the platform. You can access the AOM Command Menu using either a serial console or SSH.

Note: The availability of menu options varies depending on the platform type.

Letter	Option	Description
B	Set console baud rate	Configures the baud speed for connecting to AOM using the serial console. Select from these options: <ul style="list-style-type: none"> • 9600 • 19200 (default) • 38400 • 57600 • 115200
I	Display platform information	Displays information about the AOM firmware and bootloader, chassis serial and part numbers, blade serial number, MAC address, and power status for the active console.
P	Power on/off host subsystem	Powers the host subsystem on or off.
R	Reset host subsystem	Resets the host subsystem with a hardware reset. <i>Important: F5[®] does not recommend using this option under typical circumstances. It does not allow for graceful shutdown of the system.</i>
N	Configure AOM network	Runs the AOM network configuration utility. This utility enables you to reconfigure the IP address, netmask, and default gateway used by AOM. If you use this option while connected using SSH, your session will be disconnected as a part of the network configuration operation. <i>Note: This option is not available when you are connected using SSH.</i>
S	Configure SSH Server	Sets a session idle timeout (in seconds) for the AOM SSH server. Available values are 0 (no timeout; default value), or between 30 and 86400 (one day).
A	Reset AOM	Resets the AOM subsystem. In this case, the system is reset with a hardware reset. <i>Important: We do not recommend using this option under normal circumstances. It does not allow for graceful shutdown of the system.</i>
H	Host Console Capture Buffer	Buffers the last 4K bytes of console output from the host and saves it to a non-volatile storage location. <i>Important: This option is hidden and disabled by default. It is intended to be used as a diagnostic tool by F5 Support. When this option is enabled, then disabled, the buffer is cleared.</i>
E	Display error report	Displays a list of latched events/errors or out-of-range sensors.
Q	Quit menu and return to console	Exits the AOM Command Menu and returns to terminal emulation mode.

Accessing the AOM Command Menu from the serial console

You can access the AOM Command Menu using the front panel serial console.

1. Connect to the system using the serial console.
2. Open the AOM Command Menu.
Esc (

Configuring the management network

You can assign a management IP address, netmask, and gateway to access AOM either manually or with DHCP.

1. Connect to the system using the serial console.
2. Open the AOM Command Menu.
Esc (
3. Type `n` to open the AOM management network configurator.
4. Assign a management IP address, netmask, and gateway:
 - To use DHCP to assign the addresses, type `y` when prompted about using DHCP.
 - To manually assign the addresses, type `n` when prompted about using DHCP. At the prompts, type values for IP address (required), netmask (required), and gateway (optional).

A confirmation message displays the configured management IP address, netmask, and gateway.
5. (Optional) Type `i` to verify the assigned addresses.

Accessing the AOM Command Menu using SSH

Before you access the AOM Command Menu using SSH, you must assign a management IP address, netmask, and gateway for AOM. You can assign the addresses manually or with DHCP.

You can access the AOM Command Menu remotely using SSH from a management workstation that is connected to the same subnet as the platform's management (MGMT) interface.

Note: On this platform, AOM allows only one SSH connection at a time.

1. Open an SSH session, where `<ip addr>` is the IP address that you configured for AOM.
ssh root@<ip addr>
2. Type the root password.
3. Open the AOM Command Menu.
Esc (

Setting an SSH idle session timeout

You can specify a timeout value (in seconds) for idle AOM SSH sessions. You can access the AOM Command Menu using either a serial console or SSH.

1. Connect to the system using the serial console.
2. Open the AOM Command Menu.
Esc (
3. Type `s` to configure a timeout value for idle SSH sessions.
4. Type a timeout value.

The default value is 0 (no timeout). Available values are 0, or between 30 and 86400 (one day).

Disabling network configuration

You can connect to the system's serial console to disable SSH access to AOM over the network. This does not affect console access to AOM.

1. Connect to the system using the serial console.
2. Open the AOM Command Menu.
Esc (
3. Type n to open the AOM management network configurator.
4. Type n when prompted about using DHCP.
5. Type 0.0.0.0 at the IP address prompt.
A confirmation message displays the configured management IP address, netmask, and gateway.
6. (Optional) Type i to verify that network configuration is disabled.

About the host console capture buffer

When enabled, the host console capture buffer (H) option in the AOM Command Menu buffers the last 4K bytes of console output from the host and saves it to a non-volatile storage location.

Important: This option is intended to be used as a diagnostic tool by F5[®] Technical Support.

Enabling the host console capture buffer

1. Connect to the system using the serial console or by opening an SSH session to the AOM management IP address.
2. Open the AOM Command Menu.
Esc (
3. Enable the host console capture buffer (H) option.
Esc h
4. When prompted to confirm, type y.
This message displays: Host console capture buffer enabled.
The host console capture buffer (H) option now displays in the AOM Command Menu.

Showing the host console capture buffer

1. Connect to the system using the serial console or by opening an SSH session to the AOM management IP address.
2. Open the AOM Command Menu.
Esc (
3. Type h to select the host console capture buffer option.
This message displays: The host console capture buffer is actively capturing.
4. Type s to show the contents of the buffer.

Disabling the host console capture buffer

When you no longer require use of the host console capture buffer, you can disable it.

1. Connect to the system using the serial console or by opening an SSH session to the AOM management IP address.
2. Open the AOM Command Menu.
Esc (
3. Type `h` to select the host console capture buffer option.
This message displays: `The host console capture buffer is actively capturing.`
4. Type `d` to disable the host console capture buffer.
5. When prompted to confirm, type `y`.
This message displays: `Host console capture buffer disabled.`
The buffer is cleared, and the host console capture buffer (H) option no longer displays in the AOM Command Menu.

Platform Installation

About installing the platform

After you have reviewed the hardware requirements and become familiar with the 10000 Series platform, you can install the unit.

Important: Before you install this platform, review the environmental guidelines to make sure that you are installing and using the platform into a compatible rack and in the appropriate environment.

Determining which rack mounting kit to use

The 10000 Series platform comes with two types of rack mounting kits: sliding quick-install rail-mounting and stationary front-mounting. An advantage of installing the quick-install kit is that you can then slide the unit in and out of the rack as needed.

The tasks required to install the platform might differ depending on the type of rack mount you decide to use or which type of cabinet unit you are installing into (single two-post cabinet or four-post cabinet).

About the front-mounting kit

You can use the front-mounting kit if you are installing into a two-post rack.

Note: You should use the front-mounting kit to install the platform only if you are installing into a two-post rack. For installing the platform into all other types of racks or cabinets, you should use the quick-install rail kit.

Front-mounting kit hardware

The front-mounting kit includes these hardware parts.

Quantity	Hardware
2	Front-mounting brackets
6	M4 x 10mm flat head screws

Installing using a front-mounting kit

This platform includes front-mounting brackets, which you can use to attach the unit directly to the rack.

1. Align the bracket's keyhole slots with the PEM (brand) fasteners on the side of the unit.
2. Slide the bracket toward the front of the unit to lock the bracket into place.

Important: You must secure the bracket to the unit using three of the flat head screws provided with the platform.



3. Repeat steps 1 and 2 for the other bracket.
4. Secure the front-mounting brackets to the rack using four rack manufacturer-provided screws (two per side).
The unit must be securely fastened to the rack to provide adequate stability and to prevent the unit from falling out of the rack.
5. Attach the front bezel to the unit by grasping the bezel on either side using the indentations provided.

Note: Failure to use the indentations could result in pinched fingers.

If the rack you have does not provide adequate support for the unit, you might need a shelf kit. F5 recommends using a shelf kit created by the rack manufacturer, if available.

About the quick-install rail kit

Use the quick-install rail kit if you want to be able to slide the unit in or out of the rack for maintenance activities. The kit includes two rails (left and right) and eight #8-32 thumb screws. The rails snap into place in the rack, and no tools are required to install a platform using this kit.

The rails are optimized for installation into square hole cabinets, but they can be installed in other cabinet styles, such as round hole cabinets, using the screws provided. The rails are easily converted to mount to either cabinet style.



Figure 5: Quick-install rail kit


For information about installing the platform using the quick-install rail kit, see the instruction guide provided by the manufacturer, which is included with the kit hardware.

After installing the platform, secure it to the rack with the rail lock brackets that are provided. Attach the front bezel to the unit by grasping the bezel using the indentations located on either side.

Installing the rail lock brackets

The rail lock brackets help secure a quick-install, rail kit-mounted platform to a rack.

1. Attach the rail lock brackets to each side of the unit using the M4 flat head screws that are included in the kit.



2. Slide the unit into the rack, and then secure the rail lock brackets to the rack on each side of the unit using the #8-32 captive thumb screws on the bracket.
Use 18 to 20 inch-pounds (2.0 to 2.3 Newton-meters) of torque on these screws.

About grounding the platform

You should ground the platform after you install it in a rack. The chassis ground lug is located on the back of the platform.

Do not secure multiple bonding or grounding connectors with the same bolt. The grounding connectors do not need to be removed to perform service or installation procedures. You can connect other bonding or grounding conductors to a grounding connector provided a reliable bond between the connector and the equipment is not disturbed during installation, service, or maintenance of the platform.

Important: All grounding cable terminal lugs must meet appropriate safety standards.

Note: The platform must be grounded to a common bonding network (CBN).



Figure 6: Chassis ground lug

Connecting the ground lug to the ground terminal

After the unit is installed in the rack and before you provide power to the system, you need to connect the grounding hardware.

1. Attach a grounding terminal lug to 12 AWG copper ground wire.
2. Install the #8-32 Keps nuts on the ground terminal lugs.
Use 60 to 70 inch-pounds (6.8 to 8.0 Newton-meters) of torque on these Keps nuts.
3. Connect the ground wire to a common bonding network (CBN).

About powering the platform

The AC platform ships with two power cords that you must use with the installed power supplies to power the unit.

For DC platforms, the nominal operating DC voltage is 48 Volts.

Note: *The power cables included with this unit are for exclusive use with this unit and should not be used with other electrical appliances.*

Connecting the cables and other hardware

After you have installed the unit into the rack, connect the cables and other hardware.

Important: *In the event that network access is impaired or not yet configured, the serial console might be the only way to access the unit. You should perform all installations and upgrades using the serial console, as these procedures require reboots, in which network connectivity is lost temporarily.*

1. Connect an Ethernet cable to the MGMT port if you are using the default network configured on the management interface.

Note: *For EMI compliance, shielded cables are required for the MGMT port, and the shield must be grounded at both ends.*

2. Connect to a serial console server. Depending on which BIG-IP® system you have, you can use either the supplied RJ45 to DB9 console port cable or the RJ45F to RJ45M rolled serial adapter to connect the BIG-IP system to a serial console.
 - Connect the RJ45 to DB9 console port cable to the CONSOLE port on the BIG-IP system.

Note: The default baud rate is 19200,n,8,1.

- Connect the RJ45F to RJ45M rolled serial adapter to the console port if you are connecting the system to a serial console server with a standard CAT5 cable, and then connect the CAT5 cable to the adapter. The adapter provides the appropriate pinout connection to your equipment.



Figure 7: The RJ45F to RJ45M rolled serial (pass-through) adapter

3. For AC-powered systems, connect the power cable to the power input panel, and then connect it to the power source. For DC-powered systems, wire the DC power terminal block and connect the power supply to a DC power source.
4. Connect the serial failover cable to the FAILOVER port on each unit if you plan to set up device service clustering (DSC™) with hard-wired failover capacity.
For more information about configuring failover, see *BIG-IP® Device Service Clustering: Administration*.
5. If you have not already done so, power on the unit.

You can now assign a management IP address to the system, and then license and provision the software.

Optionally, you should run the latest version of the qkview utility. This utility collects configuration and diagnostic information about your system into a single file that you can provide to F5 Technical Support to aid in troubleshooting. For more information, see

<http://support.f5.com/kb/en-us/solutions/public/12000/800/sol12878.html>.

Configuring a management IP address using the LCD panel

You can use the LCD panel to configure the management IP address. The management IP address enables you to access the BIG-IP® Configuration utility to configure other aspects of the product, such as the product license, VLANs, and trunks. The options are located in the System menu.

Note: When using the LCD panel to configure the unit, be sure to use the Commit option to save all settings.

1. Press the X button to activate Menu mode for the LCD.
2. Press the Check button to select **System**.
3. To configure the management IP address using DHCP:

- a) Press the Check button to select **DHCP**.
 - b) Press the Check button to select **enabled**.
4. To configure the management IP address manually:
- a) Press the Check button to select **Management**.
 - b) Press the Check button to select **Address Type**, and then press the Check button again to select either **IPv4** or **IPv6**.
 - c) Use the arrow keys to select **Mgmt IP** and press the Check button.
 - d) Use the arrow keys to configure the management IP address.
 - e) Use the arrow keys to select **Prefix Length** and press the Check button.
 - f) Use the arrow keys to configure the length of the routing prefix for the IPv4 or IPv6 management IP address.
 - g) Use the arrow keys to select **Mgmt Gateway** and press the Check button.
 - h) Use the arrow keys to configure the default route for the management interface.
5. Use the arrow keys to select **Commit** and press the Check button.

Licensing the platform

Once the management IP address is configured for the platform, you can use the BIG-IP® Configuration utility to license the appropriate BIG-IP software.

1. Using a Web browser, navigate to the management IP address that you assigned to the platform.
Use this format where `<mgmt_ip_address>` is the management IP address you assigned:
`https://<mgmt_ip_address>`
2. Type `admin` as the user name and `admin` as the password.
If this is the first time you have accessed the Configuration utility, the first screen you see is the License screen.
3. Follow the instructions in the Configuration utility to license the platform.

Platform Maintenance

About maintaining the platform

The 10000 Series platform contains several components that you can replace individually without exchanging the entire system. This platform contains these replaceable components:

- AC power supply
- DC power supply
- Fan tray
- Hard drive

About AC power supplies

BIG-IP® platforms can support up to two AC power supplies. Some platforms come with only one power supply by default. You can hot swap power supplies without powering down the system if there are two installed and one remains installed and operational during the replacement process.



Figure 8: The 850W AC power supply

The platform supports power redundancy, which ensures that the system is unaffected if a single power supply fails in a system containing more than one power supply.

Caution: Running without power supplies installed in all available bays in the platform can affect cooling and electromagnetic interference (EMI). If you need to run the unit with fewer power supplies, you must install a blank supply bracket into any empty power supply bays. The blank supply bracket is required to maintain proper airflow in the system. If you do not have a blank supply bracket, leave all supplies installed and unplug any unused power supplies.

Caution: As a safety precaution, the socket outlet must be installed near the equipment and be easily accessible.

Caution: Do not mix power supply models. If two power supplies are installed in the same system, use only power supplies of the same model.

Important: You should use only one power supply type (AC or DC) in a platform. AC and DC interoperability is not supported.

Important: This product is sensitive to electrostatic discharge (ESD). F5[®] recommends that you use proper ESD grounding procedures and equipment when you install or maintain the unit.

Note: Depending on the model and revision of the power supply, you might need either a Phillips or a slotted screwdriver to replace the power supply.

Installing an AC power supply

In the event of a power supply failure, you can replace an AC power supply without powering down the system, provided that there is at least one power supply operating during the replacement process.

1. Disconnect the AC power cord from the power supply.
2. Loosen the power supply screw by turning it counterclockwise with an appropriate screwdriver, if necessary.

Note: The screw is captive and cannot be removed from the assembly.

3. Remove the power supply from the system by pulling straight toward you.
4. Slide the power supply into the empty slot.
Ensure that the power supply is fully seated in the chassis.
5. Tighten the screw into place.
The power supply is connected to the system when you tighten the screw completely.
6. Attach the power cord to the new power supply.
If the system does not boot after you apply power to the power supply, press the Check button on the LCD panel to begin booting the system.

About DC power supplies

BIG-IP[®] platforms can support up to two DC power supplies. Some platforms come with only one power supply by default. You can hot swap power supplies without powering down the system if there are two

installed and one remains installed and operational during the replacement process. The DC power supply does not have an on/off switch. You can control the power from the rack switch or the DC power source.

The DC power supply includes a DC terminal block that connects the power supply to the DC power source.

The platform supports power redundancy, which ensures that the system is unaffected if a single power supply fails in a system containing more than one power supply.



Figure 9: The 850W DC power supply




Figure 10: DC terminal block components

Caution: Before installing a DC power supply, be sure that the DC power source for the rack is powered off.

Caution: Running without power supplies installed in all available bays in the platform can affect cooling and electromagnetic interference (EMI). If you need to run the unit with fewer power supplies, you must install a blank supply bracket into any empty power supply bays. The blank supply bracket is required to maintain proper airflow in the system. If you do not have a blank supply bracket, leave all supplies installed and unplug any unused power supplies.

Caution: Before you begin to work with one of these platforms, refer to the DC-powered equipment environmental warnings for this platform and review any safety requirements for the facilities where the DC-powered platforms will be installed.

Caution: Do not mix power supply models. If two power supplies are installed in the same system, use only power supplies of the same model.

Important: You should use only one power supply type (AC or DC) in a platform. AC and DC interoperability is not supported.

Important: This product is sensitive to electrostatic discharge (ESD). F5[®] recommends that you use proper ESD grounding procedures and equipment when you install or maintain the unit.

Important: The platform must be installed in a RESTRICTED ACCESS LOCATION, such as a central office or customer premises environment.

Note: Copper cables used for grounding must meet appropriate safety standards.

Note: Bare conductors should be coated with an appropriate antioxidant before being crimped. Make sure to clean all unplated connectors, braided strap, and bus bars to a bright finish prior to coating them with the antioxidant.

Note: The platform must be grounded to a common bonding network (CBN).

Note: The battery return terminals on the platform are in an isolated DC return (DC-I) configuration.

Wiring the DC power supply terminal block

You will need these tools to assemble and wire the DC terminal block:


- Wire stripping tool
- Small Phillips screwdriver
- Small flat-head screwdriver

The 850W DC power supply includes a DC terminal block. You connect the wires to the terminal block and then insert the terminal block into the DC power supply.

1. Review the DC power supply label and determine the correct wire size for your installation.
2. Use the wire stripping tool to remove 3/8 inch (9.56 mm) of insulation.

Important: Be sure to remove the appropriate amount of insulation from each wire. If you remove too much insulation, exposed wire protruding from the terminal block can create an electrical hazard. If you do not remove enough insulation, the wire might not make proper contact with the terminal.

3. Thread the wires through the bottom of the terminal block, with the positive DC wire (typically red) on the left, the chassis ground wire in the middle, and the negative DC wire (typically black) on the right. Note the orientation of the keying notch on the terminal block. When the keying notch is up, the positive terminal is on the left.



4. Insert each exposed wire into the appropriate connector on the terminal block.
If necessary, use a small flat-head screwdriver to loosen the screws above the openings in the terminal block to open the terminal connectors.
5. Attach the wired half of the terminal block to the other half of the terminal block, and then connect the top of the terminal block until the two halves click into place.
6. Tighten the wire clamp screws on the bottom of the terminal block using a small flat-head screwdriver.
7. Insert the two gold screws that are provided with the DC power supply kit into the top and bottom of the terminal block, and then use a Phillips screwdriver to secure the two halves.



Installing a DC power supply

After you have assembled and wired the terminal block, you can install the DC power supply into the platform and connect the platform to the DC power source. The DC power supply does not have an on/off switch. You can control the power from the rack switch or the DC power source.

Important: When you connect the DC power source, F5 recommends that you follow the safety requirements defined for the facilities where the DC-powered platforms will be installed.

1. Make sure that the power from the DC power source is off.
2. Ensure that the terminal block is not connected to the power supply before adding it to the unit.
3. Remove the existing AC or DC power supply, if one is installed.
 - a) Disconnect the AC power cord or DC terminal block from the power supply.
 - b) Loosen the power supply screw by turning it counterclockwise with an appropriate screwdriver, if necessary.

Note: The screw that holds the ejector handle in place is captive and cannot be removed from the assembly.



- c) Grasp the ejector handle and rotate it downward to eject the power supply from the system.



- d) Remove the power supply from the system by pulling straight toward you.
e) Ensure that the latch on the new power supply is in the down position, and then slide the power supply into the power supply slot until the latch engages.
f) Rotate the latch upward to fully seat the power supply.
g) Tighten the screw into place.

Use 4 to 5 inch-pounds (0.45 to 0.56 Newton-meters) of torque on the screw. The power supply is connected to the system when you tighten the screw completely.

4. Loosen the power supply screw on the DC power supply by using an appropriate screwdriver, if necessary.
5. Slide the DC power supply into the power supply slot.
6. Connect the terminal block that you assembled earlier to the DC power source and be sure to connect the ground wire to a common bonding network (CBN).
7. Power on the DC power source.

If the system does not boot after you power on the DC power source, press the Check button on the LCD panel to begin booting the system.

About the fan tray

The BIG-IP[®] 10000 Series platform has a removable fan tray that is designed to maintain airflow throughout the chassis. You can change or replace the fan tray as part of the routine maintenance of the unit, or in the event of a fan failure. The fans in the fan tray run constantly while the unit is powered on. Over time, the fans can wear out, requiring you to replace the fan tray.



Figure 11: The fan tray

Important: This product is sensitive to electrostatic discharge (ESD). F5[®] recommends that you use proper ESD grounding procedures and equipment when you install or maintain the unit.

Replacing the fan tray

You do not need special tools to replace the fan tray. You do not need to power down the unit when replacing the fan tray; however, F5 highly recommends that you do not leave the unit operating without a fan tray for longer than 30 seconds.

Caution: Operating the unit without a fan tray for more than 30 seconds might cause permanent damage.

1. Stand at the back of the platform and locate the ejector handle on the fan tray.
2. Loosen the fan tray screws by turning them counterclockwise with a Phillips screwdriver, if necessary.

Note: The screws that hold the ejector handle in place are captive and cannot be removed from the assembly.



3. Grasp the ejector handle and rotate it downward to eject the fan tray from the system.



4. Remove the fan tray from the system by pulling straight toward you.



5. Ensure that the handle on the new fan tray is in the down position and slide the fan tray into the fan tray slot until the latch engages.
6. Rotate the handle upward to fully seat the fan tray.
7. Tighten the screws into place.
The fan tray is connected to the system when you tighten the screws completely. Once seated, the fan tray automatically powers up and begins circulating air through the chassis.

About the hard disk drives

The BIG-IP® 10000 Series platform includes two hot swappable hard disk drives (HDDs) and supports hard disk drive mirroring using RAID. You can change or replace the drives as part of routine maintenance of the unit or in the event of a drive failure.



Figure 12: Orientation of the 10000 Series platform hard drive bays

1. Hard disk drive bay 1

2. Hard disk drive bay 2

Identifying a faulty hard disk drive

To access the hard disk drives (HDDs), you must first remove the bezel from the unit.

Before you remove the HDD from the system, you should first identify the faulty drive.

1. Open the Traffic Management Shell (tmsh).

```
tmsh
```

2. View the status of the drives.

```
show sys raid
```

A disk summary similar to this example displays:

```
-----
Sys::Raid::Array: MD1
-----
Size (MB)  931.5K

-----
Sys::Raid::ArrayMembers
Bay ID  Serial Number  Name  Array Member  Array Status
-----
1       WD-WXG1C52Y5088  HD2   yes           failed
2       WD-WXP1C52U8160  HD1   yes           ok

-----
Sys::Raid::Bay
Bay  Shelf  Name  Serial Number  Array Member  Array Status
-----
1    1      HD2   WD-WXG1C52Y5088  yes           failed
2    1      HD1   WD-WXP1C52U8160  yes           ok

-----
Sys::Raid::Disk
Name  Serial Number  Array Member  Array Status  Model
-----
HD1   WD-WXP1C52U8160  yes          ok            ATA        WDC WD1000CHTZ-0
HD2   WD-WXG1C52Y5088  yes          failed        ATA        WDC WD1000CHTZ-0
```

3. Make note of the bay number and serial number for the faulty HDD.

Note: You can also locate the last seven digits of the serial number on the front of the drive. The serial number is printed in its entirety on the labels, on top of the drive.

4. Before you physically remove the HDD from the system, remove the faulty drive from the array.

The faulty drive is HD2 in the example.

```
modify sys raid array MD1 remove HD2
```

5. (Optional) To ensure that you remove the correct drive, you can make the LED blink for the failed drive.

The faulty drive is in bay 1 in the example.

```
modify sys raid bay 1 flash-led
```

Note: If the faulty drive is not responsive, it might not blink the LED.

Note: The LED on the drive assembly continues to blink until the failed drive is removed. When the new drive assembly is inserted, the LED blinks until the new drive assembly is added to the array and begins the replication process.

Next, you can physically remove the HDD and replace it with the new one that you received from F5. You do not have to power down the system before you remove the drive.

Replacing a hard disk drive tray

After you have identified and removed the faulty hard disk drive (HDD) from the platform, you can install the replacement drive that you received from F5®.

1. Remove the front bezel from the unit, if it is still installed.
2. Verify the location of the faulty HDD by comparing the serial number and drive bay that you noted earlier.

Note: The last seven digits of the serial number are printed on the front of the drive, behind the metal grille.

Note: The STAT LED for the failed hard disk drive will be lit solid amber.

3. Remove the faulty drive:
 - a) Loosen the HDD screw by turning it counterclockwise with an appropriate screwdriver, if necessary.

Note: The screw that holds the ejector handle in place is captive and cannot be removed from the assembly.

- b) Grasp the ejector handle and pull straight toward you to eject the drive tray from the system.
4. Slide the new HDD into the empty drive bay, by pushing the front of the tray to engage the handle until it swings closed.
5. Tighten the screw into place.

Use 4 to 5 inch-pounds (0.45 to 0.56 Newton-meters) of torque on the screw. The HDD is connected to the system when you tighten the screw completely.

6. View the status of the HDDs.
`tmsh show sys raid disk`

A disk summary similar to this example, displays:

```
-----
Sys::Raid::Disk
Name  Serial Number      Array  Array Status  Model
      Serial Number      Member
-----
HD1   WD-WXP1C52U8160   yes    ok             WDC WD1000CHTZ-0
HD2   WD-WXG1C52Y5088   yes    undefined      WDC WD1000CHTZ-0
```

The status of the replacement HDD is undefined, and the serial number should match that of the replacement drive.

Note: If after a few seconds, you do not see the additional HDD in the disk summary, the drive might not be seated properly. If this occurs, remove and reinsert the drive.

7. Add the replacement drive (HD2 in the example) to the array.

```
tmsl modify sys raid array MD1 add HD2
```

The status of the replacement drive should change to replicating, and the STAT LED should change to solid green. The replication process typically takes between 15 and 45 minutes.

8. Attach the front bezel to the unit by grasping the bezel using the indentations located on either side.

Note: Failure to use the indentations could result in pinched fingers.

Environmental Guidelines

General environmental and installation guidelines

The 10000 platform is an industrial network appliance that is designed to be mounted in a standard 19-inch EIA rack. Follow these guidelines to adhere to safety precautions:

- Install the rack according to the manufacturer's instructions and check the rack for stability before placing equipment in it.
- Build and position the rack so that after you install the platform, the power supply and the vents on both the front and back of the unit remain unobstructed. The platform must have adequate ventilation around the unit at all times.
- Although not required, a 1U space between units makes it easier for you to remove the unit from the rack in the event that the unit requires service. A 1U space between units also provides additional cable routing options.
- Leaving at least 100 mm of space from the front panel of the unit to the rack front or rack door provides enough room for you to route the cables without excessive bending or insulation damage.
- A shelf or similar device is required to support the unit if only one person is installing the unit.
- Do not allow the air temperature in the room to exceed 104°F (40°C).

***Note:** NEBS-certified units can withstand air temperatures of up to 131°F (55°C). Reaching the maximum temperature is required only for a short period of time.*


- Do not plug the unit into a branch circuit shared by more electronic equipment than the circuit is designed to manage safely at one time.

***Warning:** Due to the weight of the platform, at least two people are required to install this chassis into a rack. Failing to use two people can result in severe personal injury or equipment damage.*

***Important:** This product is sensitive to electrostatic discharge (ESD). F5[®] recommends that you use proper ESD grounding procedures and equipment when you install or maintain the unit.*


***Caution:** Customers should not attempt to replace batteries. There is a risk of explosion if a battery is replaced with an incorrect type. Field technicians should dispose of used batteries according to the instructions.*

***Attention:** Il y a risque d'explosion si la batterie est remplacée par une batterie de type incorrect. Mettre au rebut les batteries usagées conformément aux instructions.*



 This equipment is not intended for operator serviceability. To prevent injury and to preserve the manufacturer's warranty, allow only qualified service personnel to service the equipment.

Cet appareil n'a pas été conçu de sorte à être réparé par l'utilisateur. Pour prévenir les blessures et préserver la garantie du fabricant, l'appareil ne doit être réparé que par du personnel de réparation qualifié.

 The controller contains a lithium battery. There is danger of an explosion if you replace the lithium battery incorrectly. We recommend that you replace the battery only with the same type of battery originally installed in the unit, or with an equivalent type recommended by the battery manufacturer. Be sure to discard all used batteries according to the manufacturer's instructions.

Le contrôleur contient une pile au lithium. Le remplacement incorrect de la pile au lithium risque de provoquer une explosion. Nous vous recommandons de remplacer la pile uniquement par un type de pile identique à celui qui était installé à l'origine dans l'appareil ou par un type équivalent recommandé par le fabricant de pile. Assurez-vous de jeter toutes les piles usées conformément aux instructions du fabricant et aux lois locales.

Guidelines for AC-powered equipment

An AC-powered installation must meet these requirements:

- Use a 15 amp external branch circuit protection device to install the unit.
- Use one power feed for each individual power supply.

Important: *The platform must be installed in a RESTRICTED ACCESS LOCATION, such as a central office or customer premises environment.*

Note: *The power cables included with this unit are for exclusive use with this unit and should not be used with other electrical appliances.*

Note: *These guidelines apply to STATIONARY PLUGGABLE EQUIPMENT TYPE A with simultaneous multiple connections to the AC MAINS SUPPLY:*


- The building installation shall provide a means for connection to protective earth; and
 - The equipment is to be connected to that means; and
 - A SERVICE PERSON shall check whether or not the socket-outlet from which the equipment is to be powered provides a connection to the building protective earth. If not, the SERVICE PERSON shall arrange for the installation of a PROTECTIVE EARTHING CONDUCTOR from the separate protective earthing terminal to the protective earth wire in the building.
-

Note: *High leakage current. Earth connection essential before connecting supply.*

Guidelines for DC-powered equipment

A DC-powered installation must meet these requirements:

- Use a 15 amp external branch circuit protection device to install the unit.
- For permanently connected equipment, incorporate a readily accessible disconnect in the fixed wiring.
- Use only copper conductors.
- Cabling for the system must be grounded on both sides.
- Use one power feed for each individual power supply.



NEBS platform guidelines

This information applies to the Network Equipment-Building System (NEBS) version of the 10000 Series platform.

This equipment meets NEBS requirements per GR-63-CORE.

This equipment is suitable for installation in these locations:

- Network Telecommunication Facilities
- Locations where the National Electrical Code (NEC) applies

Important: *The intra-building interfaces of this platform, including Ethernet, are suitable for connection to intra-building or unexposed wiring or cabling only with shielded and grounded cables at both ends. The intra-building ports of the equipment must not be metallically connected to interfaces that connect to the outside plant (OSP) or its wiring.*

Note: *You should coat bare conductors with an appropriate antioxidant compound before you make crimp connections. You should bring all unplated connectors, braided strap, and bus bars to a bright finish and then coat them with an antioxidant before you connect them.*

Platform airflow diagram

When you install the platform into a rack, it is important to understand the unit's airflow direction so that you can ensure proper cooling.

The platform employs a negative pressure fan system, which draws cold air in from the front of the chassis.




Figure 13: Airflow in the 10000 Series platform

Platform Specifications

General specifications for system features

This table lists general specifications for system features for the 10000 Series platform.

Item	Specification
Transceiver modules hot swap	Support for hot swap of SFP, SFP+, and QSFP+ transceiver modules
Power supply hot swap	Support for hot swap of the power supplies
Jumbo frames	Support for maximum Ethernet frame size of 9216 bytes and MTU of 9128 bytes
Virtual Clustered Multiprocessing™ (vCMP™)	Supports provisioning and managing multiple, hosted instances of the BIG-IP software on a single hardware device

Important: Specifications are subject to change without notification.

Platform hardware specifications - 10000 Series

This table lists hardware specifications for the 10000 Series (10000/10050/10055/10200v-FIPS) platforms.

Item	Specification
Dimensions	H: 3.45 inches (8.76 cm) x W: 17.3 inches (43.94 cm) x D: 21.4 inches (54.36 cm) (per unit) 2U industry standard rack-mount chassis
Weight	40 pounds (18.14 kg) with one power supply, two hard disk drives, and bezel installed (per unit) 43 pounds (19.50 kg) with two power supplies, two hard disk drives, and bezel installed (per unit) 39.4 pounds (17.87 kg) with one power supply, one solid-state drive, and bezel installed (per unit) 42.4 pounds (19.23 kg) with two power supplies, one solid-state drive, and bezel installed (per unit) 42.6 pounds (19.32 kg) with two power supplies, two solid-state drives, and bezel installed (per unit) <ul style="list-style-type: none">• Front mount rack brackets add 2 pounds (0.9 kg).• Quick install rail kit adds 5.5 pounds (2.27 kg).
Processor	1 x Six-Core Intel® Xeon® processor (total 12 hyperthreaded logical processing cores)
Communication interfaces	16 x 10GbE SFP+ 2 x 40GbE QSFP+ fiber ports 1 x 10/100/1000 Ethernet Management port

Item	Specification
	1 x RJ45 console port 1 x RJ45 failover port 2 x USB 2.0 interfaces
Storage drive capacity	2 x 1 TB hard disk drive (HDD) 1 x 400 GB solid-state drive (SSD) (10050 platform only) 2 x 400 GB solid-state drive (SSD) (10055 platform only)
RAM	48 GB
AC power supply	2 x 850 W 90 - 125 VAC(+/- 10%) or 200 - 240 VAC(+/- 10%) AUTO Switching 2 x NEMA 5-15P power cords
DC power supply	2 x 850W DC Operating range: 44 to 72 VDC Minimum start up voltage: 44 VDC
<hr/> <p><i>Note: Power supply will not start below 44 VDC.</i></p> <hr/>	

Important: Specifications are subject to change without notification.

Important: F5® only provides support for F5-branded or F5-provided optical modules.

Platform hardware specifications - 10150 Series

This table lists hardware specifications for the 10150 Series platform.

Item	Specification
Dimensions	H: 3.45 inches (8.76 cm) x W: 17.3 inches (43.94 cm) x D: 21.4 inches (54.36 cm) (per unit) 2U industry standard rack-mount chassis
Weight	39.4 pounds (17.87 kg) with one power supply, one solid-state drive, and bezel installed (per unit) 42.4 pounds (19.23 kg) with two power supplies, one solid-state drive, and bezel installed (per unit) <ul style="list-style-type: none"> • Front mount rack brackets add 2 pounds (0.9 kg). • Quick install rail kit adds 5.5 pounds (2.27 kg).
Processor	1 x 10-Core Intel® Xeon® processor (total 20 hyperthreaded logical processing cores)
Communication interfaces	16 x 10GbE SFP+ 2 x 40GbE QSFP+ fiber ports 1 x 10/100/1000 Ethernet Management port 1 x RJ45 console port 1 x RJ45 failover port 2 x USB 2.0 interfaces
Solid-state drive capacity	1 x 800 GB solid-state drive (SSD)
RAM	128 GB

Item	Specification
AC power supply (non-NEBS models only)	2 x 850 W 90 - 125 VAC(+/- 10%) or 200 - 240 VAC(+/- 10%) AUTO Switching 2 x NEMA 5-15P power cords
DC power supply (NEBS models only)	2 x 850W DC Operating range: 44 to 72 VDC Minimum start up voltage: 44 VDC
<i>Note: Power supply will not start below 44 VDC.</i>	

Important: Specifications are subject to change without notification.

Important: F5[®] only provides support for F5-branded or F5-provided optical modules.

Platform environmental operating specifications

This table lists platform environmental operating specifications.

Item	Specification
Operational temperature	32 to 104°F (0 to 40°C)
<i>Note: NEBS platforms meet NEBS requirements per GR-63-CORE.</i>	
Operational relative humidity	GR-63-CORE table 4-4 5% to 85% (40°C) non-condensing 5% to 90% (40°C) non-condensing for a maximum of 96 hours
<i>Note: NEBS platforms meet NEBS requirements per GR-63-CORE.</i>	
Non-operational temperature	-40 to 158°F (-40 to 70°C)
Non-operational relative humidity	5 to 95% (40°C) non-condensing

Important: Specifications are subject to change without notification.

Platform power specifications - 10000s/10200v

This table lists power specifications for the 10000s/10200v platforms.

Item	Single power supply	Dual power supply
Typical power draw (AC power; 50% load; temp 25°C)	110VAC input: 290W 220VAC input: 280W	110VAC input: 295W 220VAC input: 290W

Item	Single power supply	Dual power supply
Typical power draw (DC power; 50% load; temp 25°C)	48VDC input: 300W	48VDC input: 320W
Maximum power draw (AC power)	110VAC input: 450W 240VAC input: 430W	110VAC input: 470W 240VAC input: 450W
Maximum power draw (DC power)	48VDC input: 430W	48VDC input: 450W
Typical heat generated (AC power)	110VAC input: 990 BTU/hour 220VAC input: 955 BTU/hour	110VAC input: 1010 BTU/hour 220VAC input: 990 BTU/hour
Typical heat generated (DC power)	48VDC input: 1025 BTU/hour	48VDC input: 1095 BTU/hour
Maximum heat generated (AC power)	1470 BTU/hour	1535 BTU/hour
Maximum heat generated (DC power)	1470 BTU/hour	1535 BTU/hour

Important: Specifications are subject to change without notification.

Platform power specifications - 10050 Series

This table lists power specifications for the 10050 Series platform.

Item	Single power supply	Dual power supply
Typical power draw (AC power; 50% load; temp 25°C)	110VAC input: 280W 220VAC input: 265W	110VAC input: 290W 220VAC input: 290W
Typical power draw (DC power; 50% load; temp 25°C)	48VDC input: 300W	48VDC input: 310W
Maximum power draw (AC power)	110VAC input: 345W 240VAC input: 315W	110VAC input: 350W 240VAC input: 355W
Maximum power draw (DC power)	48VDC input: 365W	48VDC input: 375W
Typical heat generated (AC power)	110VAC input: 960 BTU/hour 220VAC input: 900 BTU/hour	110VAC input: 990 BTU/hour 220VAC input: 990 BTU/hour
Typical heat generated (DC power)	48VDC input: 1015 BTU/hour	48VDC input: 1050 BTU/hour
Maximum heat generated (AC power)	1065 BTU/hour	1200 BTU/hour
Maximum heat generated (DC power)	1235 BTU/hour	1280 BTU/hour

Important: Specifications are subject to change without notification.

Platform power specifications - 10200v-SSL

This table lists power specifications for the 10200v-SSL platform.

Important: Platforms that contain solid-state drives (SSDs) consume an additional 10W (maximum) per drive over platforms that contain hard disk drives (HDDs), approximately.

Item	Single power supply	Dual power supply
Typical power draw (AC power; 50% load; temp 25°C)	110VAC input: 290W 220VAC input: 290W	110VAC input: 300W 220VAC input: 300W
Typical power draw (DC power; 50% load; temp 25°C)	48VDC input: 305W	48VDC input: 335W
Maximum power draw (AC power)	90VAC input: 415W	110VAC input: 415W
Maximum power draw (DC power)	44VDC input: 425W	44VDC input: 445W
Typical heat generated (AC power)	110VAC input: 990 BTU/hour 220VAC input: 990 BTU/hour	110VAC input: 1025 BTU/hour 220VAC input: 1025 BTU/hour
Typical heat generated (DC power)	48VDC input: 1045 BTU/hour	48VDC input: 1145 BTU/hour
Maximum heat generated (AC power)	90VAC input: 1420 BTU/hour	110VAC input: 1420 BTU/hour
Maximum heat generated (DC power)	44VDC input: 1450 BTU/hour	44VDC input: 1520 BTU/hour

Important: Specifications are subject to change without notification.

Platform power specifications - 10150 Series

This table lists power specifications for the 10150 Series platform.

Item	Single power supply	Dual power supply
Typical power draw (DC power; 48VDC; 50% load; temp 25°C)	290W	320W
Maximum power draw (DC power)	380W	400W
Typical heat generated (DC power)	990 BTU/hour	1095 BTU/hour
Maximum heat generated (DC power)	1300 BTU/hour	1365 BTU/hour

Important: Specifications are subject to change without notification.

Safety requirements

This equipment complies with these requirements of the Low Voltage Directive 2006/95/EC:

EC Type Examination Certificates: Master Contract 252302

CB Scheme

EN 60950-1:2006+A11:2009+A1:2010+A12:2011

IEC 60950-1:2005, A1:2009

CSA 60950-1-07, Including Amendment 1:2011

ANSI/UL 60950-1-2011

Important: *Specifications are subject to change without notification.*

EMC requirements

USA--FCC Class A, Canada--Industry Canada Class A

This equipment complies with Subpart B of Part 15 of FCC Rules for Class A digital devices, Industry Canada ICES-003, Issue 5. Operation is subject to these two conditions:

1. This equipment may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

European Union

This equipment complies with these requirements of the EMC Directive 2004/108/EC:

As Telecommunication Network Equipment (TNE) in Both Telecom Centers and Other than Telecom Centers per (as applicable):

Directive	Required Limits
-----------	-----------------

ETSI EN 300 386 V1.5.1 (2010)

EN 55022:2010	Class A
---------------	---------

EN 61000-3-2:2006+A1:2009+A2:2009

EN 61000-3-3:2008

As Information Technology Equipment (ITE) Class A per (as applicable):

EN 55024:2010

EN 55022:2010	Class A
---------------	---------

EN 61000-3-2:2006 A1:2009+A2:2009

EN 61000-3-3:2008

Important: Specifications are subject to change without notification.

Acoustic, airflow, and altitude specifications

This table lists acoustic levels, airflow movement, and operational altitude specifications for the 10000 Series platform.

Specification type	Detail	Units	Value
Acoustic ¹	Front	dBa	64
	Left	dBa	64
	Right	dBa	62
	Rear	dBa	71
	Top		64
Altitude ²	Operational	Feet	13,000
	Non-operational	Feet	40,000
Airflow ³	Open air	CFM	260 (max)

Important: Specifications are subject to change without notification.

¹ All measurements taken at 0.6 meter with one power supply operational and fans at 75% duty cycle. Measurements recorded in Decibels A-weighting.

² Per BELCORE GR-63-CORE, section 4.1.3: This unit is functional when installed at elevations between 60m (197 feet) below sea level and 1800m (6000 feet) above sea level at the aisle ambient temperatures of 40°C.

³ Fan Tray airflow measurements taken at 100% duty cycle and in open air.

China RoHS Requirements

Hazardous substance levels for China

This table shows how the BIG-IP® 10000 Series platform components conform to the Restriction of Hazardous Substances (RoHS) Directive standards for China.

10000 / 12000 系列有害物质表
10000 / 12000 Series Hazardous Substance Table

部件名称 Part Name	有毒有害物质 Hazardous Substance					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	铬 6+ (Cr ⁶⁺)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
金属部件 Metal Parts	0	0	0	0	0	0
电源 Power Supplies	X	0	X	0	0	0
主板 Motherboard	X	0	0	0	0	0
散热器部件 Heatsink Assemblies	0	0	0	0	0	0
风扇装置 Fan Assembly	X	0	0	0	0	0
硬盘 / 固态硬盘 Hard Drives or SSDs	X	0	0	0	0	0

0: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006标准规定的限量要求以下
Expresses that this hazardous substance is below the specified limits as described in SJ/T 11363-2006.
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006标准规定的限量要求
(企业可在此处, 根据实际情况对上表中打“X”的技术原因进行进一步说明)
Expresses that this hazardous substance is above the specified limits as described in SJ/T 11363-2006.

除非另外特别的标注, 此标志为针对所涉及产品的环保使用期标志. 某些零部件会有一个不同的环保使用期(例如, 电池单元模块)贴在其产品上.
此环保使用期限只适用于产品是在产品手册中所规定的条件下工作.
The Environmentally Friendly Use Period (EFUP) for all enclosed products and their parts are per the symbol shown here, unless otherwise marked. Certain parts may have a different EFUP (for example, battery modules) and so are marked to reflect such. The Environmentally Friendly Use Period is valid only when the product is operated under the conditions defined in the product manual.



Repackaging Guidelines

About repackaging the platform

If it becomes necessary to transport the platform to another location or return it to F5[®] Networks, these guidelines will help ensure that you repackage the platform properly.

If you are running BIG-IP[®] software version 11.6 or later, you can perform a disk erase operation to erase all sensitive data from solid-state drives (SSDs) and hard disk drives (HDDs) before you return a platform to F5. For more information, see *F5[®] Platforms: Essentials*.

Important: Before returning any equipment, contact F5 to obtain a Service Order (SO) or Return Material Authorization (RMA) case number.

Important: You must use shipping materials and packaging provided by F5 when repackaging the platform.

Note: Be sure to keep a record of the tracking number and ship date. These will be needed to track lost shipments.

Note: Do not include any cables, removable XFP/SFP modules, GBICs, or other peripheral items if you are returning the platform to F5.

Repackaging the platform

The 10000 Series platform must be shipped in F5[®]-provided packaging.

Caution: To ensure your safety and to prevent damage to the platform, we highly recommend that you have at least two people remove the platform from the rack and repackage it into the shipping box.

1. Halt the platform using the LCD panel.
2. Disconnect the AC power cord or DC power supply terminal from the power supplies.
3. Disconnect the network cables and other cables from the platform, and then remove any optical modules.
4. Remove the platform from the rack.
5. Wrap the platform in the plastic wrapping, if available.
6. Lift the foam flaps and place the platform into the shipping box, and then place the accessory boxes in the foam inserts.



7. Close and seal the shipping box.



Returned Material Data Security Statement

About returned material data security

Follow these data security guidelines when returning equipment to F5[®] for reprocessing or repair. The guidelines include reprocessing procedures and optional customer-end procedures.

About memory technologies used in F5 equipment

F5[®] equipment contains volatile, battery-backed volatile, and non-volatile memory. Volatile memory loses all traces of data on power down. Battery-backed volatile memory retains data as long as battery charge is maintained. Non-volatile memory retains data indefinitely.

Volatile memory

Volatile memory loses all traces of data on power down; therefore, customer data that is stored in volatile memory is secure when power is removed from the platform. No further action is required by customers for equipment that includes volatile memory.

Battery-backed volatile memory

This F5[®] platform contains a coin battery for maintaining BIOS settings and the system clock. All data maintained by the coin battery is used only for system specific tasks. No customer data is maintained by the battery-backed volatile memory. No further action is required by customers for equipment that includes volatile memory.

Non-volatile memory

F5[®] platforms include various non-volatile memory components. These non-volatile memory components can be categorized as either user inaccessible or user accessible.

Inaccessible non-volatile memory components are programmed during manufacture or software installation. The data stored in user inaccessible non-volatile memory is used for setting voltage levels, determining the sequence of operational events, and the managing appliance operational condition. Data held within user inaccessible, non-volatile memory represents no data security risk to customers. User inaccessible, non-volatile memory cannot be modified by appliance users, and therefore, contains no customer data.

Inaccessible non-volatile memory

This table lists the inaccessible non-volatile memory in this system.

Description	Data	Customer data
Programmable firmware stores	Firmware	No
Switch Card EEPROM	Platform ID, serial number, part number, and so on.	No
PHY EEPROMs	PHY MAC address	No

Accessible non-volatile memory

This table lists the accessible non-volatile memory in this system. Not all platform variants include all of these non-volatile memory items.

Description	Data	Customer data	Data security method
Hard disk drive (HDD)	F5® product software, customer configuration, and log files	Yes	Standard reprocessing or customer removal
Solid-state drive (SSD)	F5 product software, customer configuration and log files	Yes	Standard reprocessing or customer removal
Always-On Management (AOM) Flash chip (soldered-down flash chip)	AOM boot code and customer custom configuration	Yes	Standard reprocessing or customer action
FIPS card (if present)	FIPS security domain and private keys	Yes	Standard reprocessing or customer action

About removing data from F5 components

For components that contain sensitive customer data and cannot be removed from your F5® system, you can take optional steps to remove the data from these components before you return the system to F5 for processing.

Removing sensitive data from storage drives

The hard disk drive (HDD) and solid-state drive (SSD) components included in F5® platforms might include sensitive customer data. If you purchase the HDD removal SKU, you can remove the HDD/SSD and coin battery, and these components will be replaced during F5 reprocessing. Otherwise, HDD and SSD components are processed by F5 through standard processing. You can perform a disk erase operation on your system to remove sensitive customer data.

Perform a disk erase operation using one of these methods:

- On systems running BIG-IP® software version 11.6.0 and later, you can use the F5 Disk Erase utility to remove all data on hard disk drives (HDDs) or solid-state drives (SSDs) using a single-pass, zero write disk erase operation. For more information, see <http://support.f5.com/kb/en-us/solutions/public/15000/500/sol15521.html>.
- On systems running earlier versions of BIG-IP software, you can create and use a bootable USB drive to rebuild the system with a clean image of BIG-IP software. This runs a disk erase operation

and removes the master boot record (MBR). For more information see <http://support.f5.com/kb/en-us/solutions/public/13000/100/sol113164.html>.

Removing IP address data from Always-On Management

If you have configured an IP address for the Always-On Management (AOM) subsystem, you can remove the customized IP address from the system before returning it to F5® Networks.

1. Connect to the system using the serial console.
2. Open the AOM Command Menu.
Esc (
3. Assign a new management IP address, netmask, and gateway:
 - To use DHCP to assign the addresses, type *y* when prompted about using DHCP.
 - To manually assign the addresses, type *n* when prompted about using DHCP. At the prompts, type values for IP address (required), netmask (required), and gateway (optional).

A confirmation message displays the configured management IP address, netmask, and gateway.
4. (Optional) Type *i* to verify the assigned addresses.

Removing sensitive data from an internal hardware security module (HSM)

If the system includes an internal hardware security module (HSM), also referred to as a FIPS card, you can remove the sensitive customer data from HSM before returning it to F5® Networks.

Important: *The HSM cannot be removed from the platform.*

1. Use the Configuration utility to delete all key/certificate pairs.
 - a) On the Main tab, click **System > File Management > SSL Certificate List**.
This displays the list of certificates installed on the system.
 - b) Select the certificates that you want to delete and click **Delete**.

This removes all `.crt`, `.exp`, and `.key` files from the system.

2. Log on to the command line of the system using an account with root access.
3. Initialize the HSM and reconfigure it using fictitious data.

```
run util fips-util -f init
```

For more information on using this command on a FIPS platform, see *BIG-IP® Platform: FIPS Administration*.

Important: *This deletes all keys and makes any previously exported keys unusable.*

Index

10G direct attach copper cables 22
 40GbE interfaces, See QSFP+ interfaces.
 40G interfaces, See QSFP+ interfaces.

A

acoustic specifications 55
 AC-powered equipment
 connecting to a power source 30
 guidelines 46
 AC power supply
 hot swapping 33
 airflow specifications 55
 alarm LED 15
 alert conditions
 clearing 14
 defining custom alerts 15
 altitude operational specifications 55
 Always-On Management (AOM)
 about 22
 configuring management network 24
 disabling network configuration 25
 setting SSH idle session timeout 24
 AOM, See Always-On Management (AOM).
 AOM Command Menu
 about 22
 about the host console capture buffer (H) option 25
 accessing using serial console 23
 accessing using SSH 24
 disabling the host console capture buffer 26
 enabling host console capture buffer 25
 options 22
 showing the host console capture buffer 25
 AOM host console capture buffer
 about 25
 disabling 26
 enabling 25
 showing 25
 AOM IP address data
 removing 63
 Auto-MDI/MDIX 18

B

bezel
 installing 28
 BIG-IP Configuration utility
 licensing the platform 32
 managing interfaces 16
 viewing status of all interfaces 18
 breakout cable 19

C

cables
 10G direct attach copper 22
 connecting 30

cables (*continued*)
 failover 30
 power 30
 CD/DVD-ROM drives
 support for 11
 chassis
 DC power supplies 37
 ventilation 45, 47
 chassis ground lug
 locating 29
 chassis ground wire 36
 Check button
 clearing alerts 14
 power on 13
 China material content listing, See China RoHS Directive standards.
 China RoHS Directive standards 57
 clear alert operation 14
 Configuration utility, See BIG-IP Configuration utility.
 cooling system
 platform 47

D

data communications equipment (DCE) 18
 data terminal equipment (DTE) 18
 Date and time screen 13
 DC-powered equipment
 guidelines 47
 NEBS guidelines 47
 voltage 30
 DC power supply
 connecting the DC power source 37
 hot swapping 34
 supported model 34
 terminal block 36
 wiring the DC power supply terminal 37
 wiring the DC terminal block 36
 DC terminal block
 assembling and preparing 36
 device service clustering (DSC) 30
 disk erase operation
 performing 59
 DSC, See device service clustering (DSC).
 duplex mode 18
 dynamic routing protocols 49

E

electromagnetic compatibility (EMC) certifications 54
 electrostatic discharge (ESD) 45
 EMC certifications 54
 environmental guidelines 57
 See also China RoHS Directive standards.
 environmental operating specifications 51
 ESD, See electrostatic discharge (ESD).
 Ethernet hub requirements 11

F

- failover cables 30
- fan tray
 - about 38
 - replacing the fan tray 39
- FIPS cards, See hardware security module (HSM).
- FIPS platform 9
- front mount
 - kit hardware 27
- front-mounting kits
 - installing 27

G

- Gigabit Ethernet 11
- ground lugs
 - connecting to ground terminal 30
 - locating 9, 29
- guidelines
 - battery replacement 45

H

- halting 12
- halt operation 13
- hard disk drive (HDD)
 - 40
 - disk erase operation 59
 - identifying a faulty hard disk drive 41
 - replacing 42
- hard disk drives (HDDs)
 - specifications 49
- hardware
 - AC-powered equipment 46
 - DC-powered equipment 47
- hardware requirements
 - peripherals 11
- hardware security module (HSM)
 - removing data 63
- hardware specifications 49–50
- hard-wired failover 30
- hazardous substance restrictions, See China RoHS Directive standards.
- Hold mode 13
- hot swap
 - AC power supply 33
 - DC power supply 34, 37
 - power supplies 49
 - transceiver modules 49
- hubs 11

I

- indicator LEDs
 - about 14
 - behavior 15
 - locating 9
- installation
 - guidelines 45
 - performing using serial console 11
 - recommendations for 45

- installation (*continued*)
 - spacing between units 45
- interfaces
 - about 16
 - configuring 16
 - duplex mode 18
 - managing 16
 - media type 18
 - QSFP+ 19
 - viewing status of all interfaces using Configuration utility 18
 - viewing status of all interfaces using tmsh 17
 - viewing status of a specific interface using tmsh 16
 - viewing valid media types 19
 - viewing valid media types using tmsh 18

J

- jumbo frames 49

L

- LCD config menu 12
- LCD menus 11
- LCD panel
 - about 11
 - backlight option 12
 - brightness option 12
 - contrast option 12
 - control buttons 11
 - menus 11
 - pausing on a screen 13
 - using 13

LED

- alarm 15
- network interface 21
- power supply 15
- RJ45 interface 21
- SFP+ interface 21
- status 14

license

- configuring 32
- low voltage directive 54

M

- maintenance
 - AC power supply 34
 - DC power supply 37
 - fan tray 39
 - replaceable components 33
- management interface
 - connecting Ethernet cable 30
 - enabling or disabling DHCP 12
 - setting the gateway 12
 - setting the IP address 12
 - setting the netmask 12
- management IP addresses
 - configuring using LCD panel 31
- memory technologies
 - about 61
 - battery-backed volatile memory 61

memory technologies *(continued)*
 non-volatile memory 61
 volatile memory 61

N

NEBS

air temperature 45
 guidelines 47
 operating requirements 51
 platform 9

negative pressure fan system 47

netbooting 12

network interface LEDs

appearance of 21
 QSFP+ 22
 RJ45 21
 SFP 21
 SFP+ 21

network interface specifications, See transceiver module specifications.

non-volatile memory
 types 61

O

optical interfaces, See interfaces.

P

pass-through adapter, See RJ45F to RJ45M rolled serial adapter.

pinouts

cables 22
 specifications 22

platform

about 9
 airflow 47
 clearing alerts 14
 cooling 47
 FIPS 9
 grounding 29
 halting 13
 hardware provided 10
 installing 27
 managing interfaces 16
 NEBS 9
 photos 9
 powering on 13
 putting into standby mode 14
 repackaging 59
 replaceable components 33
 resetting 14
 returning for RMA 59
 SSD 9
 SSL 9
 transporting 59
 ventilation 45, 47

platform specifications

disk drive 49–50
 environmental 51
 hardware 49–50

platform specifications *(continued)*

memory 49–50
 operating 51
 power for 10000s/10200v platforms 51
 power for 10050 Series platform 52
 power for 10150 Series platform 53
 power for 10200v-SSL platform 53
 power supply 49–50
 processor 49–50
 solid-state drive 49

ports 9

power cables 30

power cord

adding an AC power supply 34

powering off

host subsystem 14

power on operation 13

power specifications

10000s/10200v platforms 51
 10050 Series platform 52
 10150 Series platform 53
 10200v-SSL platform 53

power supplies

LED 15

power supply

installing a DC power supply 37
 replacing a DC power supply 37
 replacing an AC power supply 34
 specifications 49–50
 wiring the DC terminal block 36

Product version screen 13

PXE servers

installing software from 12

Q

qkview utility 30

QSFP+ interfaces

about 19
 breakout cables 19
 configuring bundling using the Configuration utility 20
 configuring bundling using tmsh 20
 LEDs 22
 orderable components 19

quick-install rail kits 28

R

rack mount

ears 27
 front mount 27
 general environmental guidelines 45
 quick-install rail kits 28
 screws 27
 types of kits 27

rack rails, See rail mount.

RAID status screen 13

rail lock brackets

installing 29

rail mount

installing rail lock brackets 29
 quick-install rail kits 28

- rebooting 12
- redundancy
 - system 30
- redundant system configuration 30
 - See also device service clustering (DSC).
- remote administration 11
- repackaging
 - about 59
 - platform 59
- replaceable components
 - about 33
 - AC power supply 33
 - DC power supply 34, 37
 - fan tray 38
 - hard disk drive (HDD) 40
- reset operation 14
- returned material data security
 - about 61
 - accessible non-volatile memory 62
 - battery-backed volatile memory 61
 - inaccessible non-volatile memory 61
 - memory technologies 61
 - non-volatile memory 61
 - removing data from components 62
 - volatile memory 61
- Return Material Authorization (RMA) 59
- RJ45F to RJ45M rolled serial adapter 30
- RJ45 interface LEDs 21
- RMA, See Return Material Authorization (RMA).
- Rotate mode 13

S

- safety agency approvals 54
- Screens menu 13
- serial console
 - hardware installation 11, 30
- serial failover 30
- serial port
 - setting baud rate 12
- SFP+ hot swap 49
- SFP+ interface LEDs 21
- SFP interface LEDs 21
- solid state drive (SSD)
 - disk erase operation 59
- solid-state drive (SSD)
 - power consumption in 10050 Series platform 52
 - power consumption in 10150 Series platform 53
 - supported platforms 9
- solid-state drives (SSDs)
 - specifications 49–50
- specifications
 - acoustic 55
 - airflow 55
 - altitude operational 55
 - China RoHS 57
 - disk drive 49–50
 - hardware 49–50
 - hardware operation 51
 - memory 49–50

- specifications (*continued*)
 - power for 10000s/10200v platforms 51
 - power for 10050 Series platform 52
 - power for 10150 Series platform 53
 - power for 10200v-SSL platform 53
 - power supply 49–50
 - processor 49–50
 - solid-state drive 49
 - system features 49
- SSD, See solid-state drive (SSD).
- SSL platform 9
- standby mode 14
- status LED 14
- storage drives
 - removing sensitive data 62
- switches 11
- system
 - resetting 22
 - resolving when locked up 22
- System information screen 13
- System menu 12

T

- TMOS, See Traffic Management Operating System.
- tmsh, See Traffic Management Shell (tmsh).
- Traffic Management Operating System
 - relation to AOM 22
- Traffic Management Shell (tmsh)
 - interface command 18
 - managing interfaces 16
 - viewing status of all interfaces 17
 - viewing the status of a specific interface 16
 - viewing valid media types 19
- transceiver module specifications 22
- transporting the platform 59
- two-post racks 27

U

- USB flash drives
 - support for 11
- USB ports
 - supported CD/DVD-ROM drives 11

V

- vCMP
 - compatibility with FIPS-certified platforms 9
 - platform support 49
- ventilation 45, 47
- Virtual Clustered Multiprocessing, See vCMP.

W

- warnings
 - environmental 45
- warnings, environmental 57
 - See also China RoHS Directive standards.