



# 3-DNS Installation Guide

version 4.1



---

# Service and Support Information

## Product Version

This manual applies to version 4.1 of the 3-DNS® Controller.

## Obtaining Technical Support

<b>Web</b>	tech.f5.com
<b>Phone</b>	(206) 272-6888
<b>Fax</b>	(206) 272-6802
<b>Email (support issues)</b>	support@f5.com
<b>Email (suggestions)</b>	feedback@f5.com

## Contacting F5 Networks

<b>Web</b>	www.f5.com
<b>Toll-free phone</b>	(888) 88BIG-IP
<b>Corporate phone</b>	(206) 272-5555
<b>Fax</b>	(206) 272-5556
<b>Email</b>	sales@f5.com
<b>Mailing Address</b>	401 Elliott Avenue West Seattle, Washington 98119

---

## Legal Notices

### Copyright

Copyright 1998-2001, F5 Networks, Inc. All rights reserved.

F5 Networks, Inc. (F5) believes the information it furnishes to be accurate and reliable. However, F5 assumes no responsibility for the use of this information, nor any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright, or other intellectual property right of F5 except as specifically described herein. F5 reserves the right to change specifications at any time without notice.

### Trademarks

F5 and the F5 logo, F5 Networks, BIG-IP, 3-DNS, GLOBAL-SITE, and SEE-IT are registered trademarks of F5 Networks, Inc. EDGE-FX, FireGuard, iControl, Internet Control Architecture, and IP Application Switch are trademarks of F5 Networks, Inc. In Japan, the F5 logo is trademark number 4386949, BIG-IP is trademark number 4435184, 3-DNS is trademark number 4435185, and SEE-IT is trademark number 4394516. All other product and company names are registered trademarks or trademarks of their respective holders.

### Export Regulation Notice

This product may include cryptographic software. Under the Export Administration Act, the United States government may consider it a criminal offense to export this product from the United States.

### Export Warning

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

### FCC Compliance

This equipment generates, uses, and may emit radio frequency energy. The equipment has been type tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of FCC rules, which are designed to provide reasonable protection against such radio frequency interference.

Operation of this equipment in a residential area may cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Any modifications to this device - unless expressly approved by the manufacturer - can void the user's authority to operate this equipment under part 15 of the FCC rules.

### Canadian Regulatory Compliance

This class A digital apparatus complies with Canadian I CES-003.

### Standards Compliance

The product conforms to ANSI/UL Std 1950 and Certified to CAN/CSA Std. C22.2 No. 950.

### Acknowledgments

This product includes software developed by the University of California, Berkeley and its contributors.

This product includes software developed by the Computer Systems Engineering Group at the Lawrence Berkeley Laboratory.

This product includes software developed by the NetBSD Foundation, Inc. and its contributors.

This product includes software developed by Christopher G. Demetriou for the NetBSD Project.

This product includes software developed by Adam Glass.

This product includes software developed by Christian E. Hopps.

This product includes software developed by Dean Huxley.

This product includes software developed by John Kohl.

This product includes software developed by Paul Kranenburg.

This product includes software developed by Terrence R. Lambert.

This product includes software developed by Philip A. Nelson.

---

This product includes software developed by Herb Peyerl.

This product includes software developed by Jochen Pohl for the NetBSD Project.

This product includes software developed by Chris Provenzano.

This product includes software developed by Theo de Raadt.

This product includes software developed by David Muir Sharnoff.

This product includes software developed by SigmaSoft, Th. Lockert.

This product includes software developed for the NetBSD Project by Jason R. Thorpe.

This product includes software developed by Jason R. Thorpe for And Communications, <http://www.and.com>.

This product includes software developed for the NetBSD Project by Frank Van der Linden.

This product includes software developed for the NetBSD Project by John M. Vinopal.

This product includes software developed by Christos Zoulas.

This product includes software developed by Charles Hannum.

This product includes software developed by Charles Hannum, by the University of Vermont and Stage Agricultural College and Garrett A. Wollman, by William F. Jolitz, and by the University of California, Berkeley, Lawrence Berkeley Laboratory, and its contributors.

This product includes software developed by the University of Vermont and State Agricultural College and Garrett A. Wollman.

In the following statement, "This software" refers to the Mitsumi CD-ROM driver: This software was developed by Holger Veit and Brian Moore for use with "386BSD" and similar operating systems. "Similar operating systems" includes mainly non-profit oriented systems for research and education, including but not restricted to "NetBSD," "FreeBSD," "Mach" (by CMU).

In the following statement, "This software" refers to the parallel port driver: This software is a component of "386BSD" developed by William F. Jolitz, TeleMuse.

This product includes software developed by the Apache Group for use in the Apache HTTP server project (<http://www.apache.org/>).

This product includes software developed by Darren Reed. (© 1993-1998 by Darren Reed).

This product includes software licensed from Richard H. Porter under the GNU Library General Public License (© 1998, Red Hat Software), [www.gnu.org/copyleft/lgpl.html](http://www.gnu.org/copyleft/lgpl.html).

This product includes the standard version of Perl software licensed under the Perl Artistic License (© 1997, 1998 Tom Christiansen and Nathan Torkington). All rights reserved. You may find the most current standard version of Perl at <http://www.perl.com>.

This product includes software developed by Eric Young.

Rsync was written by Andrew Tridgell and Paul Mackerras, and is available under the Gnu Public License.

This product includes Malloc library software developed by Mark Moraes. (© 1988, 1989, 1993, University of Toronto).

This product includes open SSL software developed by Eric Young ([eay@cryptsoft.com](mailto:eay@cryptsoft.com)), (© 1995-1998).

This product includes open SSH software developed by Tatu Ylonen ([ylo@cs.hut.fi](mailto:ylo@cs.hut.fi)), Espoo, Finland (© 1995).

This product includes open SSH software developed by Niels Provos (© 1999).

This product includes SSH software developed by Mindbright Technology AB, Stockholm, Sweden, [www.mindbright.se](http://www.mindbright.se), [info@mindbright.se](mailto:info@mindbright.se) (© 1998-1999).

This product includes free SSL software developed by Object Oriented Concepts, Inc., St. John's, NF, Canada (© 2000).

This product includes software developed by Object Oriented Concepts, Inc., Billerica, MA, USA (© 2000).

---



---

---

## Table of Contents

---

---





---

## 1

### Introduction

Getting started .....	1-1
Choosing a configuration tool .....	1-1
Browser support .....	1-2
Using the Administrator Kit .....	1-2
Overview of the 3-DNS Controller documentation .....	1-3
Stylistic conventions .....	1-3
Finding help and technical support resources .....	1-5

## 2

### Setting Up the Hardware

Unpacking and installing the hardware .....	2-1
Reviewing the hardware requirements .....	2-1
Familiarizing yourself with the 3-DNS Controller hardware .....	2-2
Environmental requirements and usage guidelines .....	2-4
Installing and connecting the hardware .....	2-5
Addressing hardware configuration issues .....	2-6
Setting up a stand-alone unit or a redundant system .....	2-6
Setting up fail-over for a redundant system .....	2-6
Triggering a fail-over in a redundant system .....	2-6
Using redundant systems with the sync group feature .....	2-7
Using more than one network interface .....	2-7
Setting up automatic DNS zone file management .....	2-7

## 3

### Working with the First-Time Boot Utility

Using the First-Time Boot utility .....	3-1
Gathering configuration information .....	3-1
An important note about configuring non-crypto 3-DNS Controllers .....	3-2
Starting the First-Time Boot utility .....	3-2
Defining a root password .....	3-3
Defining a host name .....	3-3
Configuring a default route .....	3-3
Configuring a time zone .....	3-4
Configuring NTP clocks .....	3-4
Configuring a redundant system .....	3-4
Configuring the interfaces .....	3-5
Configuring settings for the 3-DNS web server .....	3-6
Configuring 3-DNS web server passwords .....	3-7
Configuring remote administration .....	3-7
Configuring the 3-DNS Controller mode .....	3-8
Configuring NameSurfer for zone file management .....	3-8
Confirming your configuration settings .....	3-9
Committing your configuration settings to the system .....	3-10

## 4

### Additional Setup Options

Enabling remote login tools .....	4-1
Preparing workstations for command line access .....	4-1
Using a serial terminal .....	4-1
Configuring Sendmail .....	4-2
Finding the mail exchanger for your domain .....	4-2
Setting up Sendmail .....	4-3

### Index



I

---

---

## Introduction

---

---

- Getting started
- Using the Administrator Kit
- Finding help and technical support resources



## Getting started

Welcome to the *3-DNS Installation Guide*. Before you get started installing the controller, we recommend that you browse the *3-DNS Administrator Guide* to find the configuration solution that most closely matches your needs. Briefly review the basic configuration tasks and the few pieces of information you should gather in preparation for completing the tasks, such as IP addresses and host names.

Once you find your solution in the Administrator Guide and gather the necessary network information, turn to this Installation Guide for instructions on installing the hardware and running the First-Time Boot utility. Then return to the Administrator Guide for instructions on setting up your chosen solution.

## Choosing a configuration tool

The 3-DNS Controller provides the following web-based and command line administrative tools that make for easy setup and configuration.

### First-Time Boot utility

The First-Time Boot utility is a wizard that walks you through the initial system set up. The utility helps you quickly define basic system settings, such as a root password and the IP addresses for the interfaces that connect the 3-DNS Controller to the network. The First-Time Boot utility also helps you configure access to the 3-DNS web server, which hosts the web-based Configuration utility, as well as the NameSurfer™ application that you can use for DNS zone file management.

### Configuration utility

The Configuration utility is a web-based application that you use to configure and monitor the 3-DNS Controller. Using the Configuration utility, you can define the load balancing configuration along with the network setup, including data centers, sync groups, and servers used for load balancing and path probing. In addition, you can configure advanced features such as topology settings and the SNMP agent. The Configuration utility also monitors network traffic, current connections, load balancing statistics, and the operating system itself.

The 3-DNS web server, which hosts the Configuration utility, provides convenient access to downloads such as the SNMP MIB, and documentation for third-party applications such as the NameSurfer application.

### NameSurfer application

The NameSurfer application, distributed by F-Secure® Corporation, is a third-party application that automatically configures DNS zone files associated with domains handled by the 3-DNS Controller. You can use the NameSurfer application to configure and maintain additional DNS zone

files on 3-DNS Controllers that run as primary DNS servers. The Configuration utility provides direct access to the NameSurfer application, as well as the corresponding documentation for the application.

### 3-DNS Maintenance menu

The 3-DNS Maintenance menu is a command line utility that executes scripts which assist you in configuration and administrative tasks, such as installing the latest version of the **big3d** agent on all your systems, backing up the load balancing configuration files, or adding a new 3-DNS Controller to an existing network. You can use the 3-DNS Maintenance menu directly on the 3-DNS Controller, or you can use the menu when connected to the controller using a remote shell, such as the MindTerm SSH client (if **ssh** is configured), or an RSH client (if **rsh** is configured).

### Browser support

The Configuration utility, which provides web-based access to the 3-DNS Controller system configuration and features, supports the following browser versions:

- Netscape Navigator 4.5 through 4.7
- Microsoft Internet Explorer, versions 5.0 and 5.5

## Using the Administrator Kit

The Administrator Kit includes the following items:

#### ◆ **3-DNS Software and Documentation CD-ROM**

The 3-DNS Software and Documentation CD-ROM contains PDF files of the *3-DNS Installation Guide*, the *3-DNS Administrator Guide*, and the *3-DNS Reference Guide*. The CD-ROM also contains the Release Notes, optional software downloads, and the documentation for the NameSurfer application. You can insert the 3-DNS Software and Documentation CD-ROM into a workstation CD-ROM drive to view any of the documents. You can also use the CD-ROM as a recovery tool to reinstall the 3-DNS software in the event of a catastrophic failure.

#### ◆ **3-DNS Configuration Worksheet**

Use the Configuration Worksheet to gather the information you need to configure the 3-DNS Controller itself, as well as the load balancing configuration.

## Overview of the 3-DNS Controller documentation

The 3-DNS Controller documentation provides comprehensive information about the features of the controller, instructions for installing the controller, and configuration steps and examples. The following guides make up the 3-DNS Controller documentation:

- ◆ **3-DNS Installation Guide**

The *3-DNS Installation Guide* walks you through the basic steps needed to get the hardware plugged in and the system connected to the network. Most users turn to this guide only the first time that they set up a 3-DNS Controller. The Installation Guide also covers general network administration issues, such as setting up common network administration tools including Sendmail.

- ◆ **3-DNS Administrator Guide**

The *3-DNS Administrator Guide* describes essential configuration tasks, basic and advanced load balancing solutions, and monitoring and administration tools. For example, in the Administrator Guide, you can find everything from a basic DNS request load balancing solution to a more advanced content delivery solution.

- ◆ **3-DNS Reference Guide**

The *3-DNS Reference Guide* provides basic descriptions of individual 3-DNS Controller objects, such as wide IPs, pools, virtual servers, load balancing modes, the **big3d** agent, resource records, and production rules. It also provides syntax information for **3dnsmaint** commands, configuration utilities, the **wideip.conf** file, and system utilities.

## Stylistic conventions

To help you easily identify and understand certain types of information, this documentation uses the stylistic conventions described below.

- ◆ **WARNING**

---

*All examples in this documentation use only non-routable IP addresses. When you set up the solutions we describe, you must use IP addresses suitable to your own network in place of our sample IP addresses.*

## Identifying new terms

When we first define a new term, the term is shown in bold italic text. For example, a ***wide IP*** is a mapping of a fully-qualified domain name to a set of virtual servers that host the domain's content.

## Identifying references to objects, names, and commands

We apply bold text to a variety of items to help you easily pick them out of a block of text. These items include web addresses, IP addresses, utility names, and portions of commands, such as variables and keywords. For example, the **nslookup** command requires that you include at least one **<ip\_address>** variable.

## Identifying references to other documents

We use italic text to denote a reference to another document. In references where we provide the name of a book as well as a specific chapter or section in the book, we show the book name in bold, italic text, and the chapter or section name in italic text to help quickly differentiate the two. For example, you can find information about 3-DNS Maintenance menu commands in Chapter 6, *Administration and Monitoring*, in the ***3-DNS Administrator Guide***.

## Identifying command syntax

We show actual, complete commands in bold Courier text. Note that we do not include the corresponding screen prompt, unless the command is shown in a figure that depicts an entire command line screen. For example, the following command sets the 3-DNS Controller pool load balancing mode to Quality of Service:

```
pool_lb_mode qos
```

Table 1.1 explains additional special conventions used in command line syntax.

Item in text	Description
\	Continue to the next line without typing a line break.
< >	You enter text for the enclosed item. For example, if the command has <b>&lt;your name&gt;</b> , type in your name.
	Separates parts of a command.
[ ]	Syntax inside the brackets is optional.
...	Indicates that you can type a series of items.

**Table 1.1** *Command line conventions used in this manual*



## Finding help and technical support resources

You can find additional technical documentation about the 3-DNS Controller in the following locations:

- ◆ **Release notes**

Release notes for the 3-DNS Controller are available from the home screen of the Configuration utility. The release note contains the latest information for the current version, including a list of new features and enhancements, a list of fixes, and a list of known issues.

- ◆ **Online help for 3-DNS Controller features**

You can find help online in three different locations:

- The Configuration utility home screen has PDF versions of the guides included in the Administrator Kit. The 3-DNS Controller software upgrades replace the guides with updated versions as appropriate.
- The Configuration utility has online help for each screen. Simply click the **Help** button in the toolbar.
- Individual commands have online help, including command syntax and examples, in standard UNIX man page format. Type the command followed by the question mark option (-?), and the 3-DNS Controller displays the syntax and usage associated with the command.

- ◆ **Third-party documentation for software add-ons**

The Configuration utility contains online documentation for the third-party software included with the 3-DNS Controller, including NameSurfer.

- ◆ **Technical support through the World Wide Web**

The F5 Networks Technical Support web site, <http://tech.f5.com>, contains the Ask F5 knowledge base and provides the latest technical notes and updates for the 3-DNS Administrator Kit guides (in PDF and HTML formats). To access this site you must first email [askf5@f5.com](mailto:askf5@f5.com) and obtain a customer ID and a password.





# 2

---

## Setting Up the Hardware

---

- Unpacking and installing the hardware
- Addressing hardware configuration issues
- Setting up automatic DNS zone file management



## Unpacking and installing the hardware

Regardless of the configuration you intend to use, you need to completely install the 3-DNS Controller hardware. This chapter reviews the hardware requirements, introduces the hardware, notes the environmental issues, and gives procedures for installing the hardware. It also provides basic information about configuration and management issues for redundant systems, multiple network interfaces, and DNS zone files.

The two basic tasks you must complete to get the 3-DNS Controller installed and set up are as follows:

- ◆ Connect the peripheral hardware and connect the 3-DNS Controller to the network.
- ◆ Turn the system on and run the First-Time Boot utility.  
The First-Time Boot utility is a wizard that helps you configure basic system elements such as administrative passwords, IP addresses, and host names for both the root system and the 3-DNS web server. For more information on configuring your 3-DNS Controller, see Chapter 3, *Working with the First-Time Boot Utility*.

## Reviewing the hardware requirements

The 3-DNS Controller comes with the hardware you need for installation and maintenance. However, you must provide standard peripheral hardware, such as a keyboard and monitor or serial terminal.

## Hardware provided with the 3-DNS Controller

When you unpack the 3-DNS Controller, make sure the following components are included:

- One power cable
- One PC/AT-to-PS/2 keyboard adapter
- Four rack-mounting screws
- Two keys for the front panel lock
- One extra fan filter
- One 3-DNS Administrator Kit, which includes the 3-DNS Software and Documentation CD-ROM and the Configuration Worksheet.

If you purchase a hardware-based redundant system, you also receive one fail-over cable to connect the two controllers together (network-based redundant systems do not require a fail-over cable).

## Peripheral hardware that you provide

For each 3-DNS Controller in the system, you need to provide the following peripheral hardware:

- ◆ Standard input/output hardware for direct administrative access to the 3-DNS Controller. Either of the following options is acceptable:
  - VGA monitor and PC/AT-compatible keyboard
  - Serial terminal and a null modem cable. (See *Using a serial terminal*, on page 4-1, for serial terminal configuration information.)
- ◆ Network hubs, switches, or concentrators to connect to the 3-DNS Controller network interfaces. The devices you select must be compatible with the network interface cards installed in the 3-DNS Controller. The devices can support 10/100 Ethernet or Gigabit Ethernet. Note that for Ethernet, you need either a 10Mb/sec or 100 Mb/sec hub or switch.

If you plan on doing remote administration from your own PC workstation, as most users do, we recommend that you have your workstation already in place. Keep in mind that the First-Time Boot utility prompts you to enter your workstation's IP address when you set up remote administrative access.

## Familiarizing yourself with the 3-DNS Controller hardware

The 3-DNS Controller is offered in a 2U hardware configuration. Before you begin to install the 3-DNS Controller, you may want to quickly review the following figures that illustrate the controls and ports on the front and the back of a 2U 3-DNS Controller.

### Using the 2U hardware configuration


This section describes the front and back layout of a 2U 3-DNS Controller. If you have a special hardware configuration, such as those that include more than two interface cards, the ports on the back of your unit will differ slightly from those shown in Figure 2.2, on page 2-3.

#### ◆ Note

---

*The ports on the back of every 3-DNS Controller are individually labeled, so the purpose of each port should be clear.*


Figure 2.1 illustrates the front of a 2U 3-DNS Controller with the access panel open. On the front of the unit, you can turn the unit off and on, and you can reset the unit. You can also view the indicator lights for hard disk access and for the keyboard lock.



- |                        |                  |
|------------------------|------------------|
| 1. Fan filter          | 6. Power LED     |
| 2. Keyboard lock       | 7. On/off button |
| 3. Reset button        | 8. CD-ROM drive  |
| 4. Keyboard lock LED   |                  |
| 5. Hard disk drive LED |                  |

**Figure 2.1** Front view of a 2U 3-DNS Controller

Figure 2.2 illustrates the back of a 2U 3-DNS Controller. Note that all ports are labeled, even those which are not intended to be used with the 3-DNS Controller. Ports marked with an asterisk (\*) in the list following the figure are not used by the 3-DNS Controller, and you do not need to connect them to any peripheral hardware.



- |                   |                               |
|-------------------|-------------------------------|
| 1. Fan            | 8. Serial terminal port       |
| 2. Power in       | 9. Video (VGA) port           |
| 3. Power out      | 10. External interface (fxp0) |
| 4. Mouse port*    | 11. Internal interface (fxp1) |
| 5. Keyboard port  |                               |
| 6. Fail-over port |                               |
| 7. Printer port*  |                               |

\*Not to be connected to any peripheral hardware.

**Figure 2.2** Back view of a 2U 3-DNS Controller

## Environmental requirements and usage guidelines

A 3-DNS Controller is an industrial network appliance, designed to be mounted in a standard 19-inch rack. To ensure safe installation and operation of the unit:

- Install the rack according to the manufacturer's instructions, and check the rack for stability before placing equipment in it.
- Build and position the rack so that once you install the 3-DNS Controller, the power supply and the vents on both the front and back of the unit remain unobstructed. The 3-DNS Controller must have adequate ventilation around the unit at all times.
- Do not allow the air temperature in the room to exceed 40° C (104° F).
- Do not plug the unit into a branch circuit shared by more electronic equipment than the circuit is designed to manage safely at one time.
- Verify that the voltage selector is set appropriately before connecting the power cable to the unit.



**The unit must be connected to Earth ground, and it should have a reliable ground path maintained at all times.**



**The 3-DNS Controller contains a lithium battery. There is danger of an explosion if you replace the lithium battery incorrectly. We recommend that you replace the battery only with the same type of battery originally installed in the unit, or with an equivalent type recommended by the battery manufacturer. Be sure to discard all used batteries according to the manufacturer's instructions.**



**This equipment is not intended for operator serviceability. To prevent injury and to preserve the manufacturer's warranty, allow only qualified service personnel to service the equipment.**

## Guidelines for DC-powered equipment

A DC-powered installation must meet the following requirements:

- Install the unit using a 20 Amp external branch circuit protection device.
- For permanently connected equipment, incorporate a readily-accessible disconnect in the fixed wiring.
- Use only copper conductors.



**Install DC-powered equipment only in restricted access areas, such as dedicated equipment rooms, equipment closets, or similar locations.**



## Installing and connecting the hardware

There are six basic steps to installing the hardware. You simply need to install the controller in the rack, connect the peripheral hardware and the external and internal interfaces, and then connect the fail-over and power cables. If you have a unit with three or more network interface cards (NICs), be sure to review step 3.

---

**◆ WARNING**

*Do not turn on a 3-DNS Controller until all peripheral hardware is connected to the unit.*

### To install the hardware

1. Mount the 3-DNS Controller on the rack and secure it using the four rack-mounting screws that are provided.
2. Connect the hardware that you have chosen to use for input/output:
  - If you are using a VGA monitor and keyboard, connect the monitor connector cable to the video port (number 9 in the 2U figure) and connect the keyboard connector cable to the keyboard port (number 5 in Figure 2.2). Note that a PC/AT-to-PS/2 keyboard adapter is included with each 3-DNS Controller (see the component list on page 2-1).
  - Optionally, if you are using a serial terminal as the console, connect the serial cable to the serial terminal port (number 8 in Figure 2.2).
3. Connect the external interface (number 10 in Figure 2.2) to the network from which the 3-DNS Controller receives connection requests.

If you have purchased a unit with three or more network interface cards (NICs), be sure to note or write down how you connect the cables to the internal and external interfaces. When you run the First-Time Boot utility, it automatically detects the number of interfaces that are installed and prompts you to configure more external interfaces, if you want. It is important to select the correct external interface based on the way you have connected the cables to the back of the unit.

4. If you have a hardware-based redundant system, connect the fail-over cable to the fail-over port on each unit (number 6 in the 2U figure).
5. Connect the power cable (number 2 in the 2U figure) to the 3-DNS Controller, and then connect it to the power source.

---

**◆ WARNING**

*Before connecting the power cable to a power supply, customers outside the US should make sure that the voltage selector is set appropriately. This check is necessary only if the controller has an external voltage selector.*

## Addressing hardware configuration issues

Before you start the hardware setup, you may want to review the following items which address configuration and management issues for redundant systems, systems that use more than one network interface, and DNS zone file management.

### Setting up a stand-alone unit or a redundant system

If you are setting up a stand-alone unit, you need one IP address and host name for each of the interfaces you plan to connect to the network. If you are setting up a redundant system, you need the actual IP address for each interface in each unit. If you are connecting the redundant system to more than one network, you also need a shared IP alias for each interface.

### Setting up fail-over for a redundant system

*Hardware-based fail-over* is a redundant system that connects two 3-DNS Controller units directly to each other using a fail-over serial cable.

*Network-based fail-over* is a redundant system where two units are connected to each other either directly using an Ethernet cable, or indirectly via an Ethernet network. Of the two units in a redundant system, one runs as the *active unit*, managing all DNS resolution requests, and the other runs as the *standby unit*, waiting to take over in case the active unit fails and reboots. The communication between the units, such as fail-over notification, runs across either the fail-over cable in the hardware-based redundant system, or the network in the network-based redundant system.

When you run the First-Time Boot utility, it prompts you to enter the IP address of the other unit in the redundant system.

### Triggering a fail-over in a redundant system

The 3-DNS Controller tracks two key aspects of the system to validate system performance. In a redundant system, there are two events that indicate a system failure, and trigger a fail-over.

- If the **3dnsd** daemon becomes unresponsive, or if you manually stop the daemon using the **3ndc stop** or **3ndc restart** commands, the 3-DNS Controller treats this as a system failure and initiates a fail-over.
- If the 3-DNS Controller fails to detect any traffic on its network interfaces, it attempts to create traffic to test the integrity of the interface. If the test fails, the 3-DNS Controller treats this as a system failure and initiates a fail-over.

## Using redundant systems with the sync group feature

If you include a redundant system in a sync group, you specify the redundant system's shared IP address when you define the sync group.

## Using more than one network interface

The First-Time Boot utility automatically detects the number of interfaces installed in the 3-DNS Controller. In most instances, you need to configure only one of the interfaces. If you want to configure an additional interface, you simply enter the same type of information that you entered for the first interface.

The 3-DNS Controller now runs in three modes: node, bridge, and router. If you are running the controller in node mode, you only need to configure one interface. If you are running the 3-DNS Controller in bridge mode, you use the additional interface to connect the 3-DNS Controller to the authoritative DNS using either a cross-over cable, or through a separate switch or hub. In bridge mode, you do not need to configure the information in the First-Time Boot utility for the additional network interface. In router mode, you must configure two (or more) interfaces, on different subnets, in the First-Time Boot utility.

---

◆ **Note**

*For more information about the 3-DNS Controller modes, refer to **Configuring the 3-DNS Controller mode**, on page 3-8.*

## Setting up automatic DNS zone file management

If you choose to run the 3-DNS Controller in node mode (that is, as the primary name server for your domain), First-Time Boot utility asks you if you want to use the NameSurfer application as the primary name server for DNS zone files. We recommend that you always run NameSurfer as the primary name server for DNS zone files. When you define or modify wide IPs in the Configuration utility, NameSurfer automatically makes the corresponding changes to the DNS zone files. The NameSurfer application also provides you with easy management of high-level domain zone files unrelated to the wide IP configuration.

If you plan on transferring existing BIND files from a primary DNS server to the 3-DNS Controller, you do not configure the NameSurfer application when you run the First-Time Boot utility; you configure the application later

on in the installation process. For more details about this and other DNS zone file management issues, refer to Chapter 2, *Essential Configuration Tasks*, in the *3-DNS Administrator Guide*.

◆ **Note**

---

*If you run the 3-DNS Controller in router or bridge mode, you do not configure the NameSurfer application because the 3-DNS Controller is not the authoritative DNS for your domain.*



# 3

---

## Working with the First-Time Boot Utility

---

- Using the First-Time Boot utility
- Starting the First-Time Boot utility
- Configuring settings for the 3-DNS web server
- Configuring remote administration
- Configuring the 3-DNS Controller mode
- Configuring NameSurfer for zone file management
- Confirming your configuration settings
- Committing your configuration settings to the system



## Using the First-Time Boot utility

The First-Time Boot utility is a wizard that walks you through a brief series of required configuration tasks, such as defining a root password and configuring IP addresses for the network interfaces. Once you complete the First-Time Boot utility, you can connect to the 3-DNS Controller from a remote workstation or through a web browser and begin configuring your load balancing setup.

The First-Time Boot utility is organized into three phases: configure, confirm, and commit. Each phase walks you through a series of screens, so that you can configure the following settings:

- Root password
- Host name (FQDN)
- Default route (typically a router's IP address)
- Time zone
- NTP clock synchronization
- Settings for the interface(s)
- Configuration for 3-DNS Controller redundant systems (fail-over IP address)
- Settings for remote administration
- Settings for the 3-DNS web server
- Settings for the 3-DNS Controller mode
- Settings for the NameSurfer application
- Settings for optional technical support access

First, you configure all of the required information. Next, you have the opportunity to correct, if necessary, and confirm each individual setting that you have configured. Last, your confirmed settings are committed and saved to the system. Note that the screens you see are tailored to your specific hardware and software configuration. For example, if you have a stand-alone system, the First-Time Boot utility skips the redundant system screens, and if you run the controller in bridge or router mode, the First-Time Boot utility skips the NameSurfer application screens.

## Gathering configuration information

Before you run the First-Time Boot utility on a specific 3-DNS Controller, use the Configuration Worksheet to gather the following information:

- Passwords for the root system, for the 3-DNS web server, for NameSurfer, and for technical support access (optional)
- Host names for the root system and the 3-DNS web server
- A default route (typically a router's IP address)
- Settings for the network interfaces, including IP addresses, media type, and custom netmask and broadcast addresses

- Configuration information for redundant systems, including the IP addresses of the individual controllers, and an IP address for the shared IP address
- Configuration information for browser access to the web-based Configuration utility
- The IP address or IP address range for remote administrative connections

## An important note about configuring non-crypto 3-DNS Controllers

When you run the First-Time Boot utility on a *non-crypto* 3-DNS Controller, a controller that does not use encrypted communications, certain screens are different from those shown when you run the First-Time Boot utility on a *crypto* 3-DNS Controller, a controller that uses encrypted communications.

- On crypto 3-DNS Controllers, the First-Time Boot utility prompts you to choose either SSH or RSH for remote, secure connections. We recommend that you configure an administrative IP address from which the 3-DNS Controller accepts SSH connections.
- On non-crypto 3-DNS Controllers, you can only configure an administrative IP address from which the 3-DNS Controller accepts RSH connections.
- The 3-DNS Controller stores the administrative IP address for SSH and RSH connections in the `/etc/hosts.allow` file.

### ◆ Note

---

*If you have both crypto and non-crypto 3-DNS Controllers, and you are setting up a crypto 3-DNS Controller, you need to configure the controller so that it accepts RSH and RCP connections. For more information on configuring RSH and RCP on crypto controllers, see **Enabling remote login tools**, on page 4-1.*

## Starting the First-Time Boot utility

The First-Time Boot utility starts automatically when you turn on the 3-DNS Controller (the power switch is located on the front of the controller). The first screen the controller displays is the License Agreement screen. You must scroll through the screen, read the license, and accept the agreement before you can move to the next screen. If you accept the terms of the license agreement, the next screen you see is the Welcome



screen. From this screen, simply press any key on the keyboard to start the First-Time Boot utility, and then follow the instructions on the subsequent screens to complete the process.

◆ **Note**

---

*You can re-run the First-Time Boot utility after you run it for the initial configuration. To rerun the First-Time Boot utility, type **config** at the command line.*

## Defining a root password

A root password allows you administrative access to the 3-DNS Controller. The root password must contain a minimum of 6 characters, but no more than 32 characters. Passwords are case-sensitive, and we recommend that your password contain a combination of uppercase and lowercase characters, as well as special characters. Once you enter a password, the First-Time Boot utility prompts you to confirm your root password by typing it again. If the two passwords match, your password is immediately saved. If the two passwords do not match, you receive an error message asking you to re-enter your password.

◆ **WARNING**

---

*The root password is the only setting that is saved immediately, rather than confirmed and committed at the end of the First-Time Boot utility process. You can change the root password after the First-Time Boot utility completes and you reboot the 3-DNS Controller (see Chapter 6, **Administration and Monitoring**, in the **3-DNS Administrator Guide**, for more information). You can change other system settings when the First-Time Boot utility prompts you to confirm your configuration settings.*

## Defining a host name

The host name identifies the 3-DNS Controller itself. Host names must be in the format of a fully-qualified domain name. Host names may contain letters, numbers, and the symbol for dash ( - ), however, they may not contain spaces. For example, if the controller's label is **controller1**, then you define the host name as **controller1.yourdomain.com**.

## Configuring a default route

If a 3-DNS Controller does not have a predefined static route for network traffic, the controller automatically sends traffic to the IP address that you define as the default route. Typically, a default route is set to a router's IP address.

## Configuring a time zone

Configuring a time zone ensures that the clock for the 3-DNS Controller is set correctly, and that dates and times recorded in log files correspond to the time zone of the system administrator. Scroll through the time zone list to find the time zone closest to your location. Note that one option may appear with multiple names.

## Configuring NTP clocks

You can synchronize the time on your 3-DNS Controller to a public time server by using Network Time Protocol (NTP). NTP is built on top of IP and assures accurate, local timekeeping with reference to clocks located on the Internet. This protocol is capable of synchronizing distributed clocks, within milliseconds, over long periods of time. If you choose to enable NTP, make sure UDP port 123 is open in both directions when the 3-DNS Controller is behind a firewall.

## Configuring a redundant system

When you configure the interfaces on your 3-DNS Controller, you have several options based on whether you are configuring a redundant system. On the Configure 3-DNS Interfaces screen, select **Yes, it is a redundant 3-DNS System**, if you have a redundant system. Otherwise, select **No, it is not a redundant 3-DNS System**. The subsequent configuration screens vary, based on your selection.

---

◆ **Note**

*Note that if you are configuring a redundant system, you need to select a unit ID, and configure a shared IP address for the redundant system, in addition to configuring the interfaces themselves.*

## Selecting a unit ID for redundant systems

If you are configuring a redundant system, the First-Time Boot utility prompts you to provide a unit ID and an IP address for fail-over for the 3-DNS Controller. The default unit ID number is **1**. If you are configuring the first controller in the redundant system, use the default. When you configure the second controller in the redundant system, type **2**. These unit IDs are used for active-active redundant controller configuration.

---

◆ **Note**

*If you are configuring a stand-alone controller, you do not configure a unit ID. The First-Time Boot utility goes straight to the Configure Interfaces screen.*

## Configuring the shared IP address for redundant systems

If you have a redundant system, you are also prompted to provide the IP address that serves as an IP alias for both 3-DNS Controllers. The IP alias is shared between the units, and is used only by the currently active machine. The units themselves use unique IP addresses for each interface. The First-Time Boot utility guides you through configuring the interfaces, based on your hardware configuration.

## Configuring the interfaces

The Select Interface screen shows a list of the installed interfaces. You must configure at least one interface, but you configure additional interfaces only if you want to have more than one independent network access path to the 3-DNS Controller, or if you want to run the controller in router mode.

### ◆ **WARNING**

---

*The First-Time Boot utility lists only the interfaces that it detects during boot up. If the utility lists only one interface, a network adapter may have come loose during shipping. Check the LED indicators on the network adapters to ensure that they have properly detected the 3-DNS Controller media that should be installed.*

Select the interface you want to configure, and press **Enter** (the interfaces are typically labeled **fxp0** and **fxp1**). The utility prompts you for the following information, in many cases offering you a default:

- ◆ **IP address**  
This is the IP address of the controller itself.
- ◆ **Netmask**  
Note that the 3-DNS Controller uses a default netmask appropriate to the subnet indicated by the IP address. The default netmask is shown in brackets at the prompt.
- ◆ **Broadcast address**  
The default broadcast address is a combination of the IP address and the netmask. The default broadcast address is shown in brackets at the prompt.
- ◆ **Shared IP address alias** (redundant systems only)
- ◆ **Peer IP address** (redundant systems only)  
The peer IP address is the IP address of the other unit in the redundant system. The 3-DNS Controller uses the specified peer IP address to communicate with the second unit.

◆ **Media type**

The media type options depend on the interface(s) included in your hardware configuration. The 3-DNS platform supports the following media types:

- Auto
- 10baseT
- 10baseT, FDX
- 100baseTX
- 100baseTX, FDX
- Gigabit Ethernet

## Configuring settings for the 3-DNS web server

The 3-DNS web server requires that you define a domain name for the server, a user ID, and a password. The 3-DNS web server hosts the web-based Configuration utility. The information that you configure in these screens allows you to access the Configuration utility from a web browser on your workstation. On crypto 3-DNS Controllers, the First-Time Boot utility also generates certificates for authentication.

The First-Time Boot utility guides you through a series of screens to set up web server access:

- The first screen prompts you to enter a fully-qualified domain name. The default is the host name that you entered at the beginning of the First-Time Boot utility.
- The next web server screen prompts you for a user name and a password. The password does not show on screen as you type it. The utility prompts you to enter the password again for confirmation purposes.
- The final screen prompts you to specify whether you want to allow technical support to have access to the Configuration utility.
- The certification screen prompts you to enter the country, state, city, company, and division information used for the authentication certificate (crypto 3-DNS Controllers only).

◆ **WARNING**

---

*If you ever change the IP addresses or host names on the 3-DNS Controller interfaces, you need to reconfigure the 3-DNS web server to reflect your new settings. You can reconfigure the 3-DNS web server from the command line using the following command:*

```
config_httpd
```

## Configuring 3-DNS web server passwords

The 3-DNS web server hosts the browser-based Configuration utility. If you wish to create a new password for the 3-DNS web server, after you have configured the password for the first time, run the **config httpd** command.

You can also add users to the existing password file, change a password for an existing user, or recreate the password file, without actually going through the 3-DNS web server configuration process. For more information, see Chapter 9, *Scripts*, in the **3-DNS Reference Guide**.

---

### ◆ WARNING

*If you have modified the 3-DNS web server configuration outside of the Configuration utility, be aware that some changes may be lost when you run the **config httpd** command. This utility overwrites the **httpd.conf** file, and several other files, but it does warn you before doing so.*

## Configuring remote administration

When you configure remote administration, the screens that you see vary, depending on whether you have a crypto 3-DNS Controller, or a non-crypto 3-DNS Controller.

- On crypto 3-DNS Controllers, the first screen you see is the Configure SSH screen, which prompts you to type an address for **ssh** command line access. The next screen you see is the Configure RSH screen. We recommend that you enable SSH remote administrative access, and disable RSH remote administrative access.
- On non-crypto 3-DNS Controllers, the First-Time Boot utility displays only the Configure RSH screen. Non-crypto controllers do not support SSH.

The First-Time Boot utility prompts you to enter a single IP address, or a range of IP addresses, from which the 3-DNS Controller can accept administrative connections (either remote shell connections, or connections to the 3-DNS web server). To specify a range of IP addresses, you can use the asterisk (\*) as a wildcard character in the IP addresses.

The following example allows remote administration from all hosts on the **192.168.2.100** network:

```
192.168.2.*
```

---

### ◆ WARNING

*For 3-DNS Controllers, you must configure command line access. If you do not configure command line access, the 3-DNS Controllers cannot communicate with each other, and they cannot properly exchange configuration information.*

## Configuring the 3-DNS Controller mode

The 3-DNS Controller can now run in three different modes: node, bridge, and router.

- ◆ **Node mode**

The *node mode* is the traditional installation of the 3-DNS Controller. The 3-DNS Controller replaces a DNS server in a network and uses the DNS server's IP address. All DNS traffic is directed at the 3-DNS Controller because it is registered with InterNIC as authoritative for the domain. In node mode, you usually run BIND on the system to manage DNS zone files.

- ◆ **Bridge mode**

In *bridge mode*, the 3-DNS Controller acts as a bridging device by forwarding packets between two LAN segments (usually on the same IP subnet). The controller usually has one IP address on one interface, and is installed between the router or switch and the authoritative DNS server. The 3-DNS Controller does not replace the authoritative DNS server. The 3-DNS Controller filters all DNS packets that match wide IPs, and forwards the remaining packets to the authoritative DNS server for resolution. Note that this may be the preferred method of using the 3-DNS Controller because you do not have to replace the authoritative DNS server, and you can perform out-of-band testing before you deploy 3-DNS Controller software upgrades.

- ◆ **Router mode**

In *router mode*, the 3-DNS acts as a router by forwarding packets between two different IP subnets. You can put the 3-DNS Controller anywhere in the network topology as long as packets destined for the authoritative DNS server have to pass through it. Router mode requires at least two IP addresses and two interfaces. Router mode is probably most useful for Internet service providers (ISPs) that want to redirect traffic to local content servers. For example, by using the 3-DNS Controller in router mode, an ISP can redirect requests for **ads.mydomain.net** to a local ad server.

## Configuring NameSurfer for zone file management

In the final series of the First-Time Boot utility screens, you choose whether to have NameSurfer handle DNS zone file management on the current 3-DNS Controller. If you configure the 3-DNS Controller in node mode, we strongly recommend that you configure NameSurfer to handle zone file management. If you designate NameSurfer as the primary name server, NameSurfer converts the DNS zone files on the controller, becomes the

authoritative DNS, and automatically processes changes and updates to the zone files. (You can access the NameSurfer application directly from the Configuration utility).

◆ **Note**

---

*Remember that if you run the 3-DNS Controller in bridge or router mode, the controller is not authoritative for any domains, so you do not manage any zone files on it.*

## Confirming your configuration settings

At this point, you have entered all the configuration information, and now you confirm each setting. Each confirmation screen displays a setting and prompts you to either accept or re-enter it. If you choose to edit the setting, the utility displays the original configuration screen in which you defined the setting. When you finish editing the item, you return directly to the Confirmation screen for that item, and continue the confirmation process. Note that once you accept a setting in the Confirmation screen, you do not have another opportunity to review before the commit phase.

You confirm or edit the settings in the same order that you configured them:

- Confirm host name
- Confirm default route
- Confirm all interface settings
- Confirm web server options
- Confirm SSH settings
- Confirm time zone
- Confirm NTP settings
- Confirm 3-DNS Controller mode
- Confirm administrative IP address
- Confirm NameSurfer application options

Once you have confirmed the last setting, the First-Time Boot utility moves directly into the commit phase, where you are not able to make any changes.

◆ **Tip**

---

*If, at a later time, you wish to change any of the settings that you configure using the First-Time Boot utility, simply type **config** at the command line. The **config** command starts the First-Time Boot utility.*

## Committing your configuration settings to the system

Once you confirm all of the configuration settings, the First-Time Boot utility saves the configuration settings. During the commit process, the First-Time Boot utility creates the following files and tables:

- ◆ An **/etc/hosts.allow** file  
This file stores the IP address, or IP address range, from which the 3-DNS Controller accepts administrative connections.
- ◆ An **/etc/rc.conf** file  
This file lists the utilities and daemons that are started when you reboot the controller. This file also contains any custom arguments for the daemon processes.
- ◆ An **/etc/hosts** file  
This file contains the local host's address and host name.
- ◆ A **/config/httpd/httpd.conf** file  
This file contains the configuration directives for the 3-DNS web server.
- ◆ A **named.conf** file  
This file is the configuration file for the **named** daemon. This file lists the zones for which the name server is authoritative, and it contains directives that customize the behavior of the name server.

If you want to update any of the information in these files at a later time, you can re-run the First-Time Boot utility by typing **config** at the command line. If you want to update the zone file information in the **named.conf** file, you can use the NameSurfer application in the web-based Configuration utility.

### To open the NameSurfer application

1. In the navigation pane, click **NameSurfer**.  
The NameSurfer home screen opens.
2. Edit the zone file information as required.  
For help with the NameSurfer application, click **Help** in the Name surfer navigation pane

### ◆ **WARNING**

---

*If you edit any of the files using a method other than those specified here, your changes will not be saved in the configuration database file and will be lost if you upgrade the controller.*





# 4

---

## Additional Setup Options

---

- Enabling remote login tools
- Preparing workstations for command line access
- Using a serial terminal
- Configuring Sendmail



## Enabling remote login tools

If you are setting up a crypto 3-DNS Controller that needs to communicate with non-crypto 3-DNS Controllers, you must enable the **rsh** and **rcp** tools on the crypto 3-DNS Controller. These are the standard communication and copying tools that non-crypto 3-DNS Controllers, BIG-IP Controllers, and EDGE-FX Caches use.

### To enable RSH on a crypto 3-DNS Controller

Run the **config\_rshd** script from the command line utility. The **config\_rshd** script performs several essential steps to enable access for **rsh** and **rcp**. We strongly recommend that you use the script rather than doing this manually.

## Preparing workstations for command line access

The type of system you have determines the options you have for remote command line administration:

- Crypto 3-DNS Controllers support secure shell (SSH) command line access. If you have a Windows-based PC workstation, you can use the Mindbright Mindterm SSH client to run an **ssh** session. If you have a UNIX workstation, you can use a standard **ssh** client.
- Non-crypto 3-DNS Controllers support command line access using a standard **rsh** shell.

If you are working with a crypto 3-DNS Controller, you can access the Mindterm SSH client through the web-based Configuration utility.

## Using a serial terminal

If you want to use a serial terminal (in addition to a standard console) with the 3-DNS Controller, you need only ensure that the serial terminal settings are as follows:

- 9600 baud
- 8 bits
- 1 stop bit
- No parity

## Configuring Sendmail

You can configure the 3-DNS Controller to send email notifications to you, or to other administrators, using the Sendmail utility. The 3-DNS Controller includes a sample Sendmail configuration file that you can use to start with, but you must customize the Sendmail setup for your network environment before you can use it.

Before you begin setting up Sendmail, you may need to look up the name of the mail exchanger for your domain. If you already know the name of the mail exchanger, refer to *Setting up Sendmail*, on page 4-3, for details about setting up the **sendmail** daemon itself.

### Finding the mail exchanger for your domain

You can use the **nslookup** command on any workstation that is configured for lookup. Once you find the primary IP address for your domain, you can find the mail exchanger for your domain.

#### To find the mail exchanger for your domain

1. Identify the default server name for your domain. From a workstation capable of name resolution, type the following on the command line:

```
nslookup
```

2. The command returns a default server name and corresponding IP address:

```
Default Server: <server name>  
Address: <server>
```

3. Use the domain name to query for the mail exchanger:

```
set q=mx  
<domain name>
```

The returned information includes the name of the mail exchanger. For example, the sample information shown in Figure 4.1 lists **bigip.net** as the preferred mail exchanger.

```
bigip.net preference = 10, mail exchanger = mail.domain.com  
bigip.net nameserver = ns1.bigip.net  
bigip.net nameserver = ns2.bigip.net  
bigip.net internet address = 192.168.112.1  
ns1.bigip.net internet address = 192.168.112.2  
ns2.bigip.net internet address = 192.168.112.3
```

**Figure 4.1** Sample mail exchanger information

## Setting up Sendmail

When you set up Sendmail, you must edit three configuration files. Since the 3-DNS Controller does not accept email messages, you can use the **crontab** utility to purge unsent or returned messages and send them to yourself or another administrator.

### To set up and start Sendmail

1. From the command line, open the **/etc/rc.conf** file. Add the following line to the file:

```
sendmail_enable="YES"
```

2. Save and close the **/etc/rc.conf** file.
3. To set the name of your mail exchange server, open the **/etc/mail/sendmail.cf** file and set the **DS** variable to the name of your mail exchanger. The syntax for this entry is:

```
DS<MAILHUB_OR_RELAY>
```

4. Save and close the **/etc/mail/sendmail.cf** file.

5. To allow Sendmail to purge outgoing messages that cannot be delivered immediately from the queue containing mail, open the **/etc/crontab** file, and change the last line of the file to read:

```
0,15,30,45 * * * * root /usr/sbin/sendmail -q > /dev/null 2>&1
```

6. Save and close the **/etc/crontab** file.
7. To prevent returned or undeliverable email from going unnoticed, open the **/etc/aliases** file and create an entry so that **root** points to you or another administrator at your site.

```
root: networkadmin@domain.com
```

8. Save and close the **/etc/aliases** file.
9. Run the **/usr/sbin/newaliases** command to generate a new aliases database that incorporates the information you added to the **/etc/aliases** file.

10. To turn Sendmail on, either reboot the system, or type the following command:

```
/usr/sbin/sendmail -bd -q30m
```

### ◆ Note

*The 3-DNS Controller supports only outgoing mail for Sendmail servers.*





---

---

## Index

---

---





/config/httpd/httpd.conf 3-10  
 /etc/hosts.allow file 3-2, 3-10  
 /etc/netstart file 3-10  
 /etc/rc.conf file 3-10

100baseTX 3-6  
 100baseTX, FDX 3-6  
 10baseT 3-6  
 10baseT, FDX 3-6  
 3-DNS Controller, getting started 1-1  
 3-DNS guides, types of 1-3  
 3-DNS Maintenance menu 1-2  
 3-DNS web server 1-1  
   adding users 3-7  
   changing configuration 3-6  
   configuring 3-7  
   creating a new password 3-7  
 3dnssd daemon 2-6

## A

active unit 2-6  
 Administrator Kit, PDF versions 1-5  
 Ask F5 knowledge base 1-5  
 authentication certificate  
   entering information 3-6

## B

battery, about 2-4  
 BIND files, transferring to NameSurfer 2-7  
 bridge mode  
   about 3-8  
   configuring interfaces 2-7  
 broadcast address 3-5  
 browsers, supported versions 1-2

## C

cable. See fail-over cable  
 command line access, configuring 3-7  
 command syntax, conventions 1-4  
 commands  
   config httpd 3-7  
 config httpd command 3-7  
 config\_rshd script  
   about 4-1  
   configuring rsh, rcp 4-1  
 configuration files 3-10  
 configuration tools  
   3-DNS Maintenance menu 1-1  
   Configuration utility 1-1  
   First-Time Boot utility 1-1  
   NameSurfer 1-1

Configuration utility, accessing 3-6  
 crontab utility 4-3  
 crypto controllers  
   about 3-2  
   and config\_rshd script 4-1  
   authentication certificate 3-6  
   communicating with non-crypto controllers 4-1  
   configuring rsh 4-1

## D

DC power requirements  
   for hardware installation 2-4  
 default route  
   about 3-1  
   configuring 3-3  
 DNS zone files  
   configuring 3-8  
   managing 2-7  
   managing with NameSurfer 1-1  
 documentation 1-5

## E

environmental precautions, for hardware installation 2-4  
 Ethernet interfaces. See interfaces

## F

fail-over  
   and hardware installation issues 2-6  
   and network installation issues 2-6  
   connecting the fail-over cable 2-5  
   triggering 2-6  
 fail-over cable 2-1  
 First-Time Boot utility 1-1, 2-1  
   about 3-1  
   changing the configuration 3-10  
   confirming settings 3-9  
   creating saved files 3-10  
   editing settings 3-9  
   phases 3-1  
   required information 3-1  
   saving settings 3-10  
 fully-qualified domain name  
   See host name  
 fxp0 and fxp1. See interfaces

## G

Gigabit Ethernet 3-6

## H

hardware installation  
   and DC power requirements 2-4  
   and environmental precautions 2-4  
   and environmental requirements 2-4

- and ventilation requirements 2-4
- and voltage requirements 2-4
- connecting a monitor and keyboard 2-5
- connecting a serial terminal 2-5
- connecting the fail-over cable 2-5
- connecting the interfaces 2-5
- environmental precautions 2-4
- for 2U controller 2-2
- planning 2-4, 2-6
- hardware requirements
  - for components 2-1
  - for peripherals 2-1
- hardware-based fail-over 2-6
- help, online 1-5
- host names
  - defining 3-3
  - in First-Time Boot utility 3-1
- httpd.conf file 3-7

## I

- installation issues
  - hardware-based fail-over 2-6
  - network-based fail-over 2-6
- interfaces
  - assigning IP addresses 2-6
  - configuring 3-4, 3-5
  - configuring bridge mode 2-7
  - configuring media types 3-6
  - configuring node mode 2-7
  - configuring redundant systems 2-6
  - configuring router mode 2-7
  - fxp0 label 3-5
  - fxp1 label 3-5
  - installing 2-5
  - triggering a fail-over 2-6
- Internet Explorer, supported versions 1-2

## K

- knowledge base, Ask F5 1-5

## L

- License Agreement 3-2
- lithium battery, about 2-4
- log files
  - and time zone 3-4

## M

- mail exchanger, finding 4-2
- media types 3-6

## N

- named.conf file 3-10
- NameSurfer

- as primary name server 2-7
- configuring 2-7, 3-8
- managing DNS zone files 1-1
- transferring BIND files 2-7
- updating zone files 3-10
- netmask 3-5
- Netscape Navigator, supported versions 1-2
- network interface cards (NICs). See interfaces
- Network Time Protocol (NTP) 3-4
- network-based fail-over 2-6
- node mode
  - about 3-8
  - configuring interfaces 2-7
- non-crypto controllers
  - configuring remote login 4-1
  - enabling remote login tools 4-1

## O

- online help 1-5

## P

- passwords
  - defining for root user 3-3
  - defining for web server 3-6
  - in First-Time Boot utility 3-1
- PDF versions, Administrator Kit 1-5
- peer IP address 3-5
- ports 2-2
- primary name server 2-7
- public time server 3-4

## R

- RCP
  - enabling on crypto 3-DNS Controllers 4-1
- redundant systems
  - and fail-over cable 2-1
  - and shared IP alias 3-5
  - as active unit 2-6
  - as standby unit 2-6
  - as sync group member 2-7
  - broadcasting to 2-7
  - configuring 3-2, 3-4
  - configuring interfaces 2-6
  - determining unit IDs 3-4
  - triggering a fail-over 2-6
  - using a shared IP alias 2-6
- release notes 1-5
- remote administration 3-2
  - configuring 3-7
  - planning 2-2
  - using SSH and RSH 3-2
- remote login tools, enabling 4-1
- root password 3-3
- root user, gathering password information 3-1

---

router mode  
  configuring interfaces 2-7, 3-5

RSH  
  and First-Time Boot utility 3-2  
  configuring remote administration 3-7  
  enabling on crypto 3-DNS Controllers 4-1  
  See also SSH

## S

sendmail daemon 4-2

Sendmail utility  
  about 4-2  
  configuring 4-3  
  finding mail exchanger 4-2

Serial terminal 2-2

shared IP alias 2-6, 3-5

SNMP MIB 1-1

SSH  
  and the First-Time Boot utility 3-2  
  configuring remote administration 3-7  
  See also RSH  
  viewing 3-DNS Maintenance menu 1-2

standby unit 2-6

stylistic conventions 1-3

sync groups  
  and redundant systems 2-7

system performance, triggering fail-over 2-6

## T

technical support  
  allowing web server access 3-6  
  using the web site 1-5

time zone  
  and log files 3-4  
  configuring 3-4

## U

user ID, configuring web server 3-6

utilities  
  3-DNS Maintenance menu 1-2  
  Configuration 1-1  
  crontab 4-3  
  First-Time Boot 1-1, 2-1, 3-1

## V

ventilation requirements, for hardware 2-4

## W

warnings. See environmental precautions

web server  
  allowing technical support access 3-6  
  gathering password information 3-1  
  see also 3-DNS web server

## Z

zone files  
  managing with NameSurfer 2-7  
  updating 3-10

